



Philips
CD Soundmachine with
Dynamic Bass Boost

MP3

AZ1308

Your complete MP3-CD experience

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ1308 lets you indulge in the pleasures of enjoying your favorite MP3 music with the help of easy-to-use functions.

Everything you need

- Enjoy over 10 hours of music on one MP3-CD
- Compatible with CD-Recordable and CD-ReWritable
- Dynamic Bass Boost for deep and dramatic sound

Easy to use

- Digital tuning with presets
- Multi-functional LCD display
- Stereo headphone socket

PHILIPS
sense and simplicity

Specifications

Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Programmable Tracks: 20
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play

Sound

- Output power (RMS): 2X1.0 W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary

Loudspeakers

- Built-in speakers: 2
- Finishing: Metal
- Loudspeaker types: Loudspeakers

Tuner/Reception/Transmission

- Tuner Bands: AM, FM
- Auto digital tuning
- Station presets: 20
- Antenna: FM Antenna

Connectivity

- Headphone: 3.5 mm

Convenience

- Display Digits: 5
- Display Type: LCD

Accessories

- Included Accessories: AC Power Cord, User Manual, Warranty certificate

Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

Dimensions

- Packaging dimensions (W x H x D): 325 x 180 x 280 mm
- Product dimensions (W x H x D): 290 x 150 x 230 mm
- Weight: 1.62 kg
- Weight incl. Packaging: 2.32 kg



Highlights

10 hours MP3 music on one CD



Enjoy over 10 hours of music on one MP3-CD

CD-R/RW Compatible

CD-Rewritable Compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase-change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital tuning with presets

Digital tuning with presets



Issue date 2009-08-09

Version: 1.0.5

12 NC: 9073 101 02544
UPC: 6 09585 11169 1

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com