

Philips
Docking Entertainment
System



DCM230

Enjoy iPod music in Hi-Fi sound quality

Free your iPod music and enjoy it in superb sound on the Philips DCM230. Stylishly designed with a cool metallic finish, the sleek system features smart functions and boasts total 30W RMS power for truly dynamic sound.

Play your iPod content out loud at home

- Play and charge your iPod
- USB Direct connection for portable USB MP3 players
- Play MP3/WMA-CD, CD and CD-RW
- Digital tuning for station presets

Rich and clear sound experience

- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimized music style settings
- 2x15W RMS/30W Total power

Design that blends into your interior

- Stylish desktop design with high-end metallic front panel
- Elegant design with super slim CD slot
- Single remote control for the system and iPod

PHILIPS

Specifications

iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod with color display, iPod 5th Generation

Audio Playback

- Cradle playback mode: Charging iPod, Play and Pause, Next and Previous track, Fast forward and backward
- Loader Type: Motorised, Slot
- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20
- USB Direct Modes: Delete, Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

Sound

- Sound System: Stereo
- Loudspeaker types: Bass Reflex Speaker System
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control
- Volume Control: Volume Control up/down
- Output Power: 2x15W RMS / 700W PMPO

Tuner/Reception/Transmission

- Tuner Bands: FM, MW
- Station presets: 40
- Auto digital tuning

- RDS: Station Name
- Antenna: FM Antenna

Connectivity

- USB: USB host
- Aux in: 3.5mm stereo
- Headphone: 3.5 mm

Convenience

- Display Type: LCD
- Backlight
- Remote Control: Multi-functional
- Alarms: Radio Alarm, Sleep timer
- Clock/Version: Digital

Power

- Mains power: 100-240VAC, 50/60Hz

Accessories

- Included Accessories: AC Power Cord, Warranty certificate, Remote Control, World Wide Warranty leaflet, User Manual
- User Manual: B-Portuguese, Spanish, English

Dimensions

- Product dimensions (W x H x D): 390 x 141 x 206 mm
- Packaging dimensions (W x H x D): 258 x 182 x 502 mm
- Weight incl. Packaging: 3.59 kg



Highlights

Play and charge your iPod

Enjoy your favorite MP3 music while charging your iPod! The dock lets you connect your iPod directly to the Docking entertainment system so you can listen to your favorite music in superb sound. It also charges your iPod while it plays so you can enjoy your music and not have to worry about your iPod battery running out. Use the remote control to navigate, select and playback the music stored on your iPod. The Docking entertainment system automatically charges your iPod while it is docked.

USB Direct connection

With the USB Direct mode, you can simply select the music on a USB device and playback all your content. All you have to do is plug in your USB device to playback music or export content from the device.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



Issue date 2018-03-18

Version: 2.0.4

12 NC: 8670 000 35656
EAN: 87 12581 38417 3

© 2018 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.