



Philips
Cube micro sound system

• Dock for iPod/iPhone



DCM1070



Sound that fits your home

Obsessed with sound

Dock your iPhone/iPod player with this Philips sound system. Listen to your music from one simple control. Great sound and stylish design. Sit back and relax, enjoy your music all day, your way.

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 10 W RMS total output power

Enjoy your music from multiple sources

- Play and charge your iPod/iPhone simultaneously
- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW
- MP3 Link for portable music playback
- Digital tuning with preset stations for extra convenience

PHILIPS

Highlights

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most

important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality

delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

Play and charge your iPod/iPhone



Enjoy your favourite MP3 music while charging your iPod/iPhone! The dock lets you connect your portable device directly to the Docking entertainment system so you can listen to your favourite music in superb sound. It also charges your iPod/iPhone while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The Docking entertainment system automatically charges your portable device while it is docked.

USB Direct



With the USB Direct mode, simply plug in your USB device and your digital music will be played directly from the Philips device.



Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- Others: ID3-tag support
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, programme play, repeat, shuffle, stop
- Docking playback modes: fast forward and reverse, next and previous track, play and pause

Sound

- Output power: 2 x 5 W RMS
- Sound enhancement: Dynamic Bass Boost, digital sound control
- Volume control: up/down

Loudspeakers

- Speaker drivers: 3" woofer
- Speaker types: bass reflex speaker system

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 20
- Tuner enhancement: auto digital tuning

Connectivity

- Audio/Video output: Headphone (3.5 mm)
- MP3 Link: 3.5 mm stereo line in

Convenience

- Alarms: CD alarm, radio alarm, iPod alarm, USB alarm
- Loader type: top
- Clock: on main display, sleep timer
- Display type: LCD display

- Backlight colour: white
- Charging device: iPhone, iPod

Accessories

- Cables/Connection: MP3 Link cable
- Remote control
- User Manual: multi-lingual
- Others: Quick start guide
- Warranty: Worldwide Guarantee booklet

Dimensions

- Gross weight: 3.5 kg
- Main speaker dimensions (W x D): 140 x 198 mm
- Main speaker height: 143 mm
- Main unit depth: 250 mm
- Packaging width: 516 mm
- Main unit height: 143 mm
- Packaging height: 308 mm
- Packaging depth: 195 mm
- Main unit width: 140 mm

Power

- Power supply: 110-240 V, 50/60 Hz

iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod with colour display, iPod 5th generation, iPod touch, iPod classic, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod touch 2nd generation, iPod 6th Generation, iPod nano 5th generation, iPod nano 6th generation, iPod shuffle, iPod touch 3rd generation, iPod touch 4th generation

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4, iPhone 4S



Issue date 2013-05-29

Version: 1.0.6

12 NC: 8670 000 93188
EAN: 87 12581 65444 3

© 2013 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com