Philips Docking Entertainment System



AZ1330D

Share your iPod music at home or on the go

Free your iPod music and enjoy it out loud on the Philips AZ1330D with powerful 2x4W sound. Share all your tunes and liven up any party, or just slide in a CD on the motorised loading tray to enjoy your favourite music at home.

Enjoy your favourite music

- Play and charge your iPod
- Play MP3/WMA-CD, CD and CD-RW
- Digital tuning for station presets

Superb performance in compact design

- Bass Reflex speakers deliver a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic sound
- Total power 2 x 4 W RMS

Easy to use

- Motorised CD loader for convenient access
- Make album selection from MP3 and WMA music
- Single remote control for the system and iPod



Specifications

iPod compatibility

· Compatible with: iPod, iPod mini, iPod nano, iPod with colour display, iPod 5th Generation

Audio Playback

- Cradle playback mode: Charging iPod, Play and Pause, Next and Previous track, Fast forward and reverse
- Loader Type: Motorised, Tray
- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Reverse, Next/ Previous Track Search, Repeat Play, Shuffle Play • Programmable Tracks: 20

Sound

- Output power (RMS): 2 x 4 W
- · Sound System: Stereo
- Loudspeaker types: Bass Reflex Speaker System
- Sound Enhancement: Dynamic Bass Boost
 Speaker diameter: 3"
- Volume Control: rotary

Tuner/reception/transmission

- Tuner Bands: FM, MW
- · Auto digital tuning
- Antenna: FM Antenna







Aux in

· Headphones: 3.5 mm

Convenience

- Display Type: LCD
- Backlight
- Remote Control: Multi-functional

Power

- Mains power
- Battery type: LR20
- Battery voltage: 1.5 V
- Number of batteries: 6

Accessories

 Included Accessories: Remote Control, Audio Cable, AC Power Lead, User manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D): 410 x 187 x 307 mm
- Product dimensions (W x H x D): 358.4 x 140.6 x 260 mm
- Weight: 2.22 kg • Weight incl. Packaging: 3.15 kg





Z1330D/05

Highlights

Play and charge your iPod Play and charge your iPod

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings from low to high - at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Motorised CD loader

Motorised CD loader for convenient access



Issue date 2013-05-10

© 2013 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 2.2.5

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 31636 EAN: 87 12581 34689 8

www.philips.com