



Philips  
Portable CD Player

AX3303

## Slim and Jogproof

Looking for a CD player that has great features and looks ultra cool? The AX3303 is just the ticket. The players are slim and ultra modern with a unique animated optical encasing and a variety of exciting colors for a fun music experience.

### Design for motion

- Slim Portable CD Player with round and compact footprint
- Unique animated optical casing for fun and happiness

### Jogproof

- 45-second ESP™

### Enhanced bass performance

- Digital Dynamic Bass Boost for optimized bass at any volume
- Stereo headphone with handy volume control

### Enjoy all kinds of discs

- Play CD, CD-R and CD-RW discs

# PHILIPS

# Specifications

## Sound

- Acoustic Feedback
- D/A converter: 1-bit
- Frequency response: 20 - 20 000 Hz
- Output Power: 2 x 5mW RMS
- Signal to noise ratio: > 85dB
- Sound Enhancement: Digital Dynamic Bass Boost
- Volume Control: digital

## Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 30-Track Programmable, Fast Forward/Backward, Hold, Introsan, Repeat Play, Resume Playback from stop, Shuffle Play
- Electronic Skip Protection(CD): 45

## Connectivity

- DC in: 4.0 mm, 4.5V, centre +
- Headphone: 3.5 mm
- Line-out: 3,5 mm

## Convenience

- Display Type: LCD
- Indications: battery status, Cd functions, DBB, ESP, time, track



## Accessories

- AC/DC Adaptor: AY3170(300mA)
- Batteries: AY3363(Ni-MH rechargeable)
- Headphones: SBC HE225(with volumn control)
- Included accessories: User Manual

## Dimensions

- Ebox dimensions (W x H x D): 0 x 0 x 0 mm
- Housing: Heat Resistant Body, Lenticular Sheet
- Master carton dimensions: 252 x 310 x 160 mm
- Master carton quantity: 6
- Master carton weight: 4.18 kg
- Packaging dimensions (W x H x D): 243 x 49 x 148 mm
- Packaging type: D-box
- Product dimension (WxDxH) inch: 137.5x137.5x23.3mm
- Product weight: 0.2 kg

## Power

- Battery Playing Time CD: 20
- Battery type: AA, AAA, LR03, LR6, UM3, UM4
- Kind of Battery: Rechargeable
- Rechargeable

# Highlights

## Round, slim and compact

Slim Portable CD Player with round and compact footprint

## Animated optical casing

Unique animated optical casing for fun and happiness

## 45-second ESP™

Electronic Skip Protection is a convenient feature that ensures skip-free music even when your CD player is subjected to knocks and jolts while you're jogging or on the move. Devices with Electronic Skip Protection have an intelligent electronic buffer that adjusts both its contents and laser spin speeds automatically to guarantee uninterrupted music listening.

## Digital Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom-end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimized bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

## Headphone with volumn control

Stereo headphone with handy volum control

## Play CDs, CD-R and CD-RW

Philips is known for making products which are compatible with many discs available in the market. This audio system lets you enjoy music from CD, CD-R and CD-RW. CD-RW (CD-Rewritable Compatible) means that your audio system can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players.



Issue date 2014-02-06

Version: 2.0.3

12 NC: 9073 101 00964  
EAN: 87 10895 79633 0

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)