



Philips
Portable Radio

Digital tuning
FM/MW/LW/SW

AE2480



Enjoy your favourite radio

with one-touch 40 pre-set radio stations

Compact portable radio with an extra-large, easy-to-read LCD display and 40-preset stations of FM/MW/SW/LW digital tuner.

Enjoy your favourite stations

- FM/MW/SW/LW digital tuning
- MP3 Link for portable music playback

Excellent sound reproduction

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Stereo sound system for better music enjoyment

Easy to use

- Built-in clock function
- Clock, alarm and sleep timer
- Large backlit LCD display for easy viewing in low light
- One-touch access for 40 pre-set stations

PHILIPS
sense **and** simplicity

Highlights

Built-in clock

A built-in clock keeps time accurately. When the radio is off, the clock display comes on for added convenience.

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

Clock, alarm and sleep timer

Clock, alarm and sleep timer

Large backlit LCD display



Backlit LCD display ensures easy viewing and operation in low light conditions, and provides clear information at a glance.

FM/MW/SW/LW PLL tuning

FM/MW/SW/LW digital tuning

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

40 pre-set stations

One-touch access for 40 pre-set stations

Stereo sound system

A system that receives stereo broadcasts for high power performance with exciting and lifelike sound through dual speakers.

Specifications

Tuner/Reception/Transmission

- Station presets: 40
- Tuner bands: FM, LW, MW, FM stereo, SW
- Tuner enhancement: auto digital tuning

Sound

- Volume control: up/down
- Sound system: stereo
- Output power: 1 W RMS

Connectivity

- Audio/Video output: Headphone (3.5 mm)
- MP3 Link: 3.5 mm stereo line in

Convenience

- Alarms: buzzer alarm
- Display Digits: 5
- Backlight colour: white
- Clock: sleep timer
- Display type: LCD display

Accessories

- Cables/Connection: AC-DC adapter, audio cable
- Others: User Manual

Dimensions

- Master carton quantity: 2
- Product weight: 1.33 kg
- Main unit depth: 76 mm
- Main unit height: 148 mm
- Main unit width: 218 mm

Power

- Battery type: C size (LR14)
- Battery voltage: 1.5 V
- DC input voltage: 9 V
- Number of batteries: 6
- Power supply: 220 - 240 V



Issue date 2011-07-26

Version: 2.0.8

12 NC: 8670 000 37289
EAN: 87 12581 39772 2

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com