

Philips
Universal Remote Control

4in1 TV/DVD/SAT/AMP

SRU740



Ultra flat

Stylish silver universal remote control that gives maximum functionality for most brands of TV, VCR, DVD, satellite receiver or cable set-top box.

Single control solution for most devices & brands

- Ready for use with Philips equipment
- 4-in-1 remote for your TV, STB, DVD and Receiver

Great convenience

- Battery low indication shows when to refresh batteries
- Dedicated keys for moving around menus
- A light indicates current active device mode
- Ultra flat design matching flat home entertainment devices

Quick and easy set-up

- Batteries are included for unwrap-and-zap
- For questions and assistance call our URC service line
- Automatically searches for your equipment brand
- URC support service via dedicated website

PHILIPS
sense and simplicity

Specifications

Convenience

- **Universal IR database:** TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP
- **TV functions:** Program up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu control, Colour/Brightness control, Teletext keys, Fast text keys, Previous program, Sleep/timer, 16:9, Guide, info
- **Teletext enhancements:** Fast text
- **VCR functions:** Transport keys (6), Showview, VCR plus, Menu control
- **DVD functions:** Transport keys, System menu control, Disc menu control, Digit keys
- **SAT/CBL functions:** Digit keys, Menu control, Guide, info, Favourites, Text functions
- **Ease of Installation:** Autosearch
- **Installation steps:** 2
- Copy key function
- **Language support:** GB/F/D/NL/I/E
- **Languages in manual:** GB/F/D/NL/DK/S/N/FIN/I/E/P
- **Number of keys:** 38
- Pre-programmed for Philips

- **Regulatory Approvals:** CE Mark
- Splash proof

Accessories

- **Battery:** Yes, CR2025 Coin cell Battery 3V Lithium

Power

- **Battery lifetime:** 12
- **Number of batteries:** 2

Dimensions

- **Blister dimensions (WxDxH):** 156 x 16 x 290 mm
- **Carton dimensions (WxDxH):** 181 x 70 x 310 mm
- **Master carton quantity:** 3
- **Materials:** Recycled PET A

Infrared Capabilities

- **Operating distance:** 7 m
- **Transmitting LEDs:** 1
- Universal IR code database
- **Number of brands in database:** Over 300
- **Carrier frequency range:** 24 - 55 kHz
- **Transmission angle:** 90 degree

Product highlights

4in1 home entertainment remote

Replace a table full of remote controls with one unit that'll operate your TV, satellite receiver (or cable STB set-top box) DVD player/recorder and receiver (AMP), regardless of the brand or model.

Pre-programmed for Philips

If you have Philips equipment, you can use your universal remote control without programming it because all keys are pre-set for Philips.

Ultra flat

A remote with ultra flat design is slimmer than a standard remote. This is made possible by replacing the standard batteries by coin cell batteries (the size of a coin) that take less space.

Dedicated menu keys

Dedicated keys to move easily around your equipment's menus mean simple one finger operation without having to press shift or function shift keys

Device mode indicator

Small lights keep you informed about which device mode is currently active.

Battery-low indication

To know in time when the batteries need to be recharged or replaced.

Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.



Issue date 2007-12-07

Version: 5.0

12 NC: 9082 100 03883
EAN: 87 10895 86553 1

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com