

Philips Streamium  
Wireless Music Adapter

**Streamium**

SL501



## Music here, PC there without wires

PC and Internet Music wirelessly on your stereo

### Enjoy music wirelessly from your PC

- Stream high-quality music from your PC to the audio system
- Enjoy music files from your PC wirelessly on your stereo

### Wireless access to Internet Music

- Choose your favorite Internet music to fit your mood
- Internet upgradeable to keep your product up-to-date
- Access to Internet Music Entertainment

### Ease of Use

- Local LCD display for easy navigation
- Control all the functions you need with fingertip ease
- Gain easy access to your list of favorite content

### Based on open standards

- Wireless RF communication based on open IEEE802.11 standard
- UPnP enables various devices to communicate with each other

**PHILIPS**

# Specifications

## Audio Playback

- Compression format: MP3, MP3PRO
- ID3-tag support

## Connectivity

- Audio Output - Analog: Stereo (Red/White cinch)
- Encryption / security: WEP 128 bit, WEP 64 bit
- Wireless connections: Wireless LAN(802.11b/g)

## Accessories

- CD-ROM: Philips Media Manager & Manual
- Included accessories: AC Power Cord, Audio Cable, Batteries for remote control, Mains Adaptor, Remote Control, User Manual
- Remote control
- User Manual

## Software

- Philips Media Manager: UPnP multimedia content server

## System Requirements

- CD-ROM drive
- Hard disk space: 100 MB
- PC OS: Windows® 98 SE, 2000, ME, XP
- Processor: Pentium II or better
- RAM memory: 64 MB
- PC Network required: Wireless Network
- Internet connection: Broadband Internet (>256 kbps)
- My.philips.com: Internet access and e-mail

## Power

- Mains power: AC 100-240V 50-60Hz
- On/Off switch
- Power LED indicator: Operation - Blue, Red

## Internet services

- Audio services: Live 365.com, Andante, Musicmatch Jukebox, Radio Free Virgin, Playhouse radio, ...and more
- My streams: Add your own Internet streams

# Highlights

## Wireless PC Music Link

Stream music from your PC to your audio system in high quality. Listen on your audio system to music files stored on the PC. Select songs from your music collection according to artist, album or genre.

## Wireless PC music

Bring music stored on your PC to your stereo via a wireless connection and enjoy it anywhere in your home.

## Customized Internet Music

Choose by genre from thousands of Internet music stations to fit your mood. Personalise Internet Radio to your music preferences.

## Internet upgradeable

New features, functions and media formats automatically downloaded over the Internet via a broadband connection straight into your device.

## Internet Music Entertainment

A broadband Internet connection gives you access to a huge collection of music content that is live streamed from the Internet to your Wireless Music Link. Today's selection of Internet Entertainment consists of: - 1,000s of Internet Radio stations - Access to almost any music genre - Personalized Internet Audio - create your own station - Free and subscription based services - My Streams gives access to any MP3 format radio station on the web

## LCD navigation display

Local LCD display facilitates easy navigation through your music collection.

## Infra-red remote control

Infra-red remote control provides the most convenient way to control the device without leaving your chair.

## Favorites

You can create a list in which you mark or unmark your favorite content using the remote control. Then simply use the list to quickly playback this content.

## WiFi 802.11

The WiFi standard means that no wires need to be installed between PC devices, PC peripherals and audio/video equipment located in different rooms.

## UPnP

UPnP (Universal Plug and Play) refers to a networking protocol that allows various devices to communicate with each other. Devices that can play certain content (pictures, audio or video files) can make themselves know on the network and can link into datastores that hold these files. A file can then be exchanged to enjoy a seamless entertainment experience.



Issue date 2014-02-10

Version: 2.0.3

12 NC: 9082 100 03004  
EAN: 87 10895 82089 9

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)