

Philips
Wireless HiFi Headphone

32mm drivers/closed-back
Over-ear

SHC5200



Wireless freedom

Fully rechargeable wireless headphones

No more hassles with the cables, you can feel free to move around at home for music enjoyment. With the rechargeable and lightweight design of these Philips SHC5200/79 headphones, you don't need to bother for long wearing time.

The perfect wireless listening experience

- 32mm speaker driver delivers high performance sound
- FM Wireless transmission for freedom of movement

Comfortable for long use

- Self-adjusting inner headband
- Lightweight design improves comfort for prolonged use.

Convenience

- Fully rechargeable
- Choose from 2 channels to minimize interference

PHILIPS

Specifications

Sound

- Acoustic system: Closed
- Frequency response: 10 - 20 000 Hz
- Magnet type: Neodymium
- Sensitivity: 100 dB
- Speaker diameter: 32 mm
- Impedance: 24 ohm

Tuner/Reception/Transmission

- Channel separation: > 30 dB
- Pilot tone frequency: 19 kHz
- Effective range: 100 m
- Carrier frequency range: 863.0 - 865.0 MHz
- Modulation: FM
- Number of channels: 2

Convenience

- Battery charging indication
- Double PLL
- Operating time: ~14 hours
- Automatic power off

Power

- Power supply headphone: 2 x 1.5 V NiMH R03/AAA
- Power supply transmitter: AC/DC adapter 8V/200mA

Accessories

- Audio cable
- Included accessories: Power Adapter

Packaging dimensions

- EAN: 48 95229 10673 4

- Packaging dimensions (W x H x D): 24 x 32 x 10 cm
- Gross weight: 0.754 kg
- Nett weight: 0.42 kg
- Number of products included: 1
- Packaging type: Carton
- Tare weight: 0.334 kg
- Type of shelf placement: Both
- Packaging dimensions (W x H x D): 9.4 x 12.6 x 3.9 inch
- Gross weight: 1.662 lb
- Nett weight: 0.926 lb
- Tare weight: 0.736 lb

Outer Carton

- Gross weight: 2.87 kg
- GTIN: 1 48 95229 10673 1
- Outer carton (L x W x H): 32.5 x 26 x 32.5 cm
- Nett weight: 1.26 kg
- Number of consumer packagings: 3
- Tare weight: 1.61 kg
- Gross weight: 6.327 lb
- Outer carton (L x W x H): 12.8 x 10.2 x 12.8 inch
- Nett weight: 2.778 lb
- Tare weight: 3.549 lb

Product dimensions

- Product dimensions (W x H x D): 19.5 x 22 x 8.5 cm
- Weight: 0.178 kg
- Product dimensions (W x H x D): 7.7 x 8.7 x 3.3 inch
- Weight: 0.392 lb

Highlights

32 mm speaker driver

The 32 mm speaker driver is a compact yet powerful element for delivering non-distorted sound with any given input power.

Self-adjusting inner headband

Typically headphones worn outdoors are adjustable by sliding an extendable headband into position. This can be cumbersome as it usually has to be done every time you use it. Get your music fix faster and easier with these headphones' flexible, self-adjusting inner headband. It will automatically adjust to your head's shape and size.

Lightweight design

The durable, lightweight quality materials of these Philips headphones enhance comfort for extended wearing.

FM Wireless transmission

With high frequency FM wireless transmission, which can even pass through walls, you can even listen to your music when you're in another room.

Fully rechargeable

The headphones are designed to be used with rechargeable batteries. No worry on cost for repeated use.

2 transmission channels

With a choice of two transmission channels your listening pleasure is protected because you can easily switch to the one with the best reception.

