



Philips Flite  
Headphones

32mm drivers/closed-back

Over-ear  
Soft ear cushions  
Compact folding



SHL4600VWT

## Ultra light. Big sound.

### Gravity defying headphones

Perfecting the art of simplicity, Philips Flite Aerolite headphones blend casual confidence with clean modern lines and an ultra slim form. Created to bring you clear sound and all day ease-of-use, They can also fold compact or flat.

#### True comfort

- Ultralight and super slim design
- Soft ear cushions allow for long-wearing comfort

#### Streamlined design

- Flat and compact folding for easy portability
- Enjoy music tangle-free with a flat cable design

#### Pure clarity

- High power 32mm speaker drivers for clear sound
- Over-ear design reduces ambient noise

# PHILIPS

Headphones  
32mm drivers/closed-back Over-ear, Soft ear cushions, Compact folding

SHL4600WT/00

## Highlights

### Compact folding



Flat and compact folding for easy portability.

### Clear sound



High-power 32mm tilted drivers reproduce clear, crisp sound and deep, rich bass.

### Tangle-free cable



A flat cable keeps your headphones tangle-free, while added strain relief ensures cable durability.

### Ergonomic cushions



Soft ear cushions and tilted drivers are ideal for long-wearing comfort.

### Lightweight comfort



Ultralight and super slim for complete comfort on the move.

### Over-ear design

Over-ear design reduces ambient noise

## Specifications

### Sound

- Acoustic system: Closed
- Magnet type: Neodymium
- Frequency response: 9 - 23 500 Hz
- Speaker diameter: 32 mm
- Sensitivity: 104 dB
- Maximum power input: 40 mW
- Impedance: 32 ohm

### Connectivity

- Cable Connection: one-sided
- Finishing of connector: chrome-plated
- Cable length: 1.2 m

### Outer Carton

- Length: 21.5 cm
- Number of consumer packagings: 3
- Length: 8.5 inch
- Width: 13 cm
- Gross weight: 0.833 kg
- Height: 24 cm
- GTIN: 1 69 25970 71017 3
- Width: 5.1 inch
- Height: 9.4 inch
- Nett weight: 0.378 kg
- Gross weight: 1.836 lb
- Nett weight: 0.833 lb
- Tare weight: 0.455 kg
- Tare weight: 1.003 lb

### Packaging dimensions

- Height: 22.5 cm
- Packaging type: Carton
- Type of shelf placement: Both
- Width: 19.5 cm
- Depth: 3.5 cm
- Height: 8.9 inch
- Number of products included: 1
- EAN: 69 25970 71017 6
- Width: 7.7 inch
- Gross weight: 0.222 kg
- Depth: 1.4 inch
- Nett weight: 0.126 kg
- Gross weight: 0.489 lb
- Nett weight: 0.278 lb
- Tare weight: 0.096 kg
- Tare weight: 0.212 lb

### Product dimensions

- Height: 16.5 cm
- Width: 18.5 cm
- Depth: 3 cm
- Width: 7.3 inch
- Height: 6.5 inch
- Depth: 1.2 inch
- Weight: 0.126 kg
- Weight: 0.278 lb

### Design

- Color: White



Issue date 2024-03-08

Version: 8.0.4

EAN: 69 25970 71017 6

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)