



Philips
CD Soundmachine

- MP3-CD
- Tape

AZ1047

Enjoy music wherever you go

You take pleasure in the simple things in life and delight in convenience. The compact and portable Philips CD soundmachine lets you indulge in the pleasures of enjoying your favourite music with the help of easy-to-use functions.

The ultimate listening experience

- Play MP3-CD, CD and CD-R/RW
- FM/MW tuner for radio enjoyment
- Autostop cassette deck

Easy to use

- MP3 Link for portable music playback
- CD Shuffle/Repeat for personalised music enjoyment
- 20-track CD programmable

Rich and clear sound

- Dynamic Bass Boost for deep and dramatic sound

PHILIPS

Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD
- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- Number of decks: 1
- Cassette deck technology: mechanical

Tuner/Reception/Transmission

- Tuner bands: FM, MW
- Antenna: FM antenna

Sound

- Sound enhancement: Dynamic Bass Boost
- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

Loudspeakers

- No. of built-in speakers: 2
- Speaker grille finishing: metal

Audio recording

- Tape recording enhancement: CD synchro start recording
- Recording media: tape

Convenience

- Loader type: top
- Display type: LCD display

Connectivity

- MP3 Link: 3.5 mm stereo line in

Power

- Battery type: C size (LR14)
- Number of batteries: 6
- Power supply: 220 - 240 V
- Battery voltage: 1.5 V

Accessories

- Cables/Connection: power cord
- Others: User Manual
- Warranty: Warranty Certificate

Dimensions

- Gross weight: 2.4 kg
- Packaging depth: 175 mm
- Packaging height: 275 mm
- Packaging width: 320 mm
- Weight: 1.8 kg
- Main unit depth: 243 mm
- Main unit height: 142 mm
- Main unit width: 292 mm



Highlights

Play MP3-CD, CD and CD-R/RW

MP3 stands for "MPEG 1 Audio layer-7.6 cm (3)". .MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

Autostop cassette deck

Autostop cassette deck

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

CD Shuffle/Repeat

The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favourite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.



Issue date 2013-05-10

Version: 1.0.5

12 NC: 8670 000 51191
EAN: 87 12581 47470 6

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com