



Philips
PC Camera

CIF
CMOS

SPC300NC

Simply superior performance!

Live video messaging

If you want to get into the fascinating world of face-to-face video chatting and video mails, the SPC 300NC is the smart way to get on-line and share the live action. It comes with everything you need, including v-mail software.

High picture & video quality

- Smooth image with 30 frames per second video
- VGA resolution (640x480) for sharp images

Face-to-face video chatting

- Go face-to-face with free instant messaging services
- External microphone for optimum positioning

Easy to use

- V(ideo)Launch software
- VLounge QuickLaunch button for instant operation
- Snapshot button lets you take great instant photos
- Rotating lens for perfect aiming and natural images

PHILIPS
sense and simplicity

Specifications

Video & snapshot capturing

- Sensor: CMOS
- Sensor resolution: QVGA
- Video resolution: QVGA
- Snapshot resolution: QVGA
- Interpolated snapshot res.: VGA
- Max. frame rate: 30 fps
- Lens: f: 6 mm, F2.8, D42°
- White balance: 2600 – 7600 k
- Min. illuminance: < 10 lux
- Color depth: 24 bit

Mechanics

- Laptop clamp: No
- LCD clamp: No
- CRT stand: No
- Desktop stand
- Digital built-in microphone: No
- Quicklaunch button
- Snapshot button

Accessories

- Included Accessories: Quick install guide, User

Manual, External microphone

Software

- VLounge: Basic
- Add video to: MSN Messenger, Yahoo! Messenger, AOL Messenger

System Requirements

- Operating System: Microsoft Windows 98, Microsoft Windows ME, Microsoft Windows 2000, Microsoft Windows XP
- Processor: Pentium II 500MHz or faster
- RAM memory: 128 MB RAM
- Sound card
- USB: Free USB port
- Internet connection
- Hard disk space: 200 MB
- CD-ROM or DVD-ROM Drive

Connectivity

- PC Link: USB 1.1

Highlights

30 frames per second video

Sit back and enjoy superior viewing with 30 frames per second video. This gives you smoother video images and a better all-round video-chatting experience.

VGA resolution

VGA (640 x 480) means around 300,000 pixels are used to create the total image. This VGA resolution ensures sharp images for use in documents, webpages and e-mails.

Works with all IM services

Add video to Yahoo!, MSN and AOL Messenger. This PC Camera also works with Windows Messenger and NetMeeting.

External microphone included

With a separate external microphone, you have the freedom to place it where it best picks up your voice for relaxed on-line video chatting.

VLounge software

Software for capturing, managing and archiving snapshots and video clips in a very convenient way. With just a couple of mouse clicks you will be able to create and send Video mails. This software package provides all you need to take full advantage of your Philips PC Camera.

VLounge QuickLaunch button

To start up the VLounge application, simply press the QuickLaunch button

Snapshot button

With just one press of this button, your webcam takes a picture automatically. It's a fun way to share your pictures by adding them to e-mails, web pages or documents.

Rotating lens

Rotating lens for perfect aiming and natural images. You can get the right camera angle quickly and easily without having to put things underneath it to change the tilt.



Issue date 2009-05-27

Version: 3.0.7

12 NC: 9082 100 04491
EAN: 87 10895 88525 6

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com