



Philips
Surge protector

Wall tap

1 outlet
900J of surge protection

SPN3110



Home office surge protector

918 Joules/36,000 Ampere

Plugs directly into wall without the cord clutter.

Dependable protection

- 40 dB EMI/RFI noise filtration
- €100.000 equipment warranty

Built-in convenience

- Protection indicator light

Ideal for home entertainment systems

- Coax line protection
- Power blocker

Pure Protection

- 918 joules

PHILIPS

Surge protector
Wall tap 1 outlet, 900J of surge protection

Specifications

Packaging dimensions

- Packaging dimensions (W x H x D): 14.5 x 21 x 8 cm
- Nett weight: 0.11 kg
- Gross weight: 0.2 kg
- Tare weight: 0.09 kg
- EAN: 87 12581 36884 5
- Number of products included: 1
- Packaging type: Blister
- Type of shelf placement: Both

Outer Carton

- Outer carton (L x W x H): 26 x 16.5 x 23.5 cm
- Nett weight: 0.33 kg
- Gross weight: 1 kg
- Tare weight: 0.67 kg
- EAN: 87 12581 36885 2
- Number of consumer packagings: 3

Product dimensions

- Product dimensions (W x H x D): 7 x 10.5 x 7.7 cm
- Weight: 0.11 kg

SPN3110/10

Highlights

40 dB EMI/RFI noise filtration

Built-in filtering technology ensures the best performance from your components. It guards against signal interference and loss of data. The higher the dB rating the better the noise reduction.

Protection indicator light

This LED alert lights up to indicate the surge protector is working properly.

Coax line protection

Connectors route the coaxial signal through the surge protector to protect against surges and spikes.

Power blocker

This automatic shutdown technology senses when the device has reached capacity and automatically shuts down electricity to your equipment. It protects against subsequent surges, even if you are not present

€100.000 equipment warranty

Protects your connected equipment for the life of the product.



Issue date 2017-12-07

Version: 2.1.10

12 NC: 8670 000 34461
EAN: 87 12581 36884 5

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com