



Philips
USB power bank

20,000 mAh
3 USB charging ports
QC 3.0 and PD 3.0
PPS

DLP7721C



Powerful power bank

with a portable back-up power pack

Big 20,000mAh capacity with safe Li-polymer battery. No more hassle when your cellphone is out of battery. Fast charge your device with USB-C PD 3.0 Max 20W or USB-A port with QC 3.0 Max 18W output.

Superior Charging Design

- 50% charge in 30 minutes
- Charging using USB-C Programmable Power Supply (PPS)
- Smart protection against overheat, overvoltage & overcurrent
- 3 USB ports charge three devices simultaneously
- USB-A with QC fast charging
- USB-C PD 20W charging port

Portable power

- Works anywhere - great when you're not near a power source

Confirm operation at a glance

- LED power-indicator light

PHILIPS

USB power bank
20,000 mAh 3 USB charging ports, QC 3.0 and PD 3.0, PPS

Specifications

Compatibility

- Works with the following: USB charged devices

Power

- Output: USB-C Max 20W USB-A Max 18w
- Power input: Type-C 5V/3A, MicroUSB 5V/2A
- Battery Capacity: 20,000mAh 74Wh

Packaging dimensions

- Number of products included: 1
- Type of shelf placement: Both
- Packaging dimensions (W x H x D):
9.5 x 17 x 3.5 cm
- Packaging dimensions (W x H x D):
3.7 x 6.7 x 1.4 inch
- EAN: 48 95229 13553 6

Outer Carton

- Number of consumer packagings: 18
- Outer carton (L x W x H): 34 x 24 x 22.5 cm
- Outer carton (L x W x H): 13.4 x 9.4 x 8.9 inch
- GTIN: 1 48 95229 13553 3



Inner Carton

- Number of consumer packagings: 6
- Inner carton (L x W x H): 22 x 10.7 x 20.5 cm
- Inner carton (L x W x H): 8.7 x 4.2 x 8.1 inch
- GTIN: 2 48 95229 13553 0

Accessories

- User Manual: User Manual
- Cables: USB-C charging cable

Product dimensions

- Product dimensions (W x H x D):
6.8 x 13.6 x 2.75 cm
- Product dimensions (W x H x D):
2.7 x 5.4 x 1.1 inch
- Weight: 0.355 kg
- Weight: 0.783 lb

Design and finishing

- Materials: PC + ABS

DLP7721C/00

Highlights

USB-C PD 20W charging port.\

Equipped with USB-C (Power Delivery) PD 20W fast charging port.

USB-A with QC fast charging

Quick Charge (QC) fast charging technology delivers faster charging by increasing voltage and current. It uses Quick Charge protocol to optimize charging speeds for compatible devices, reducing charge times

50% charge in 30 min

Fast charging - Charge your mobile phone empty to 50% in 30 minutes time.

Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real-time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.

Smart Protection

Smart protection against overheating, overvoltage and overcurrent

LED power-indicator light

The discreet LED light glows softly to let you know at a glance that the unit is powered.



Issue date 2023-10-11

Version: 3.3.2

12 NC: 8670 001 89995
EAN: 48 95229 13553 6

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com