

Philips  
DVD Micro Theater

DVD playback  
component design

MCD119



## Enjoy a great movie experience

Now you can truly experience the audio-visual thrill of the cinema in your living room! The stylish MCD119 DVD Micro Theater features Progressive Scan for optimized images, plus Dynamic Bass Boost for deep and rich bass sound.

### Enjoy your favorite movies, photos and music

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience
- Progressive Scan component video for optimized image quality

### Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Aux-in to enhance TV sound
- 20W RMS total output power

### Start the day your way

- Alarm Time Display shows you the wake-up call time
- Sleep timer for easy falling asleep to your favorite music

# PHILIPS

# Highlights

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.



# Specifications

## Sound

- Output Power: 2x10W RMS
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital

## Loudspeakers

- Main Speaker: 4" woofer

## Video Playback

- Playback Media: DivX, DVD+RW, DVD-Video, Picture CD, Video CD/SVCD, DVD
- Disc Playback Modes: Angle, PBC, Slow Motion, Zoom, Parental control, A-B Repeat, OSD, Resume Playback from Stop
- DVD Region.: 2
- Video Enhancement: Progressive Scan

## Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Top

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo

- Station presets: 40
- Auto digital tuning

## Connectivity

- Video Output - Analog: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch)
- Aux in: 1x(L/R)/ RCA
- Other connections: FM Antenna, Line out

## Convenience

- Alarms: Sleep timer, CD Alarm, Radio Alarm
- Clock: On main display
- Display Type: White FTD
- OSD Languages: English, French, Spanish, German, Italian, Portuguese
- Eco Power Standby: 1 watt

## Accessories

- Included accessories: Composite video cable (Y), FM antenna
- Remote control: 38-key with Lithium batteries

## Dimensions

- Set dimensions (W x H x D):  
218 x 90 x 221.5 mm
- Main speaker dimensions (W x H x D):  
125 x 250 x 232 mm



Issue date 2014-02-06

Version: 1.0.8

12 NC: 9073 100 13422  
EAN: 87 10895 97180 5

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)