www.philips.com/welcome



PHILIPS

Contents

1	Notice	4
	Copyright	4
	Compliance	4
	Trademarks	4
2	Important	5
	Safety	5 5 5
	Care for your product	5
	Care of the environment	6
3	Your home theater	6
	Main unit	6
	Remote control	7
4	Connect your home theater	8
	Speakers	8
	Connectors	9
	Connect to TV	10
	Connect audio from TV and other device	s 11
5	Use your home theater	12
	Choose sound	12
	Discs	12
	USB storage devices	13
	DivX	14
	Audio, video, and picture options	14
	Radio	15
	MP3 player	16
	Create MP3 files	16
	EasyLink	17
6	Change settings	18
	Picture	18
	Sound	18
	Language	19
	Parental control	19
	Energy saving	20
	Apply factory settings	20
7	Update software	21
	Check software version	21
	Update software through USB or CD-R	21

8	Product specifications	22
9	Troubleshooting	23
10	Index	25

1 Notice

This section contains the legal and trademark notices.

Copyright



This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.

Compliance



This product is in compliance with the essential requirements and other relevant provisions of Directives 2006/95/EC (Low Voltage), 2004/108/EC (EMC).

Trademarks



Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.



DivX $^{\circ}$, DivX Certified $^{\circ}$ and associated logos are registered trademarks of DivX, Inc. and are used under license.

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, Inc. This is an official DivX Certified® device that plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX video.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified * device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.



HDMI, and HDMI logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI licensing LLC in the United States and other countries.



2 Important

Read and understand all instructions before you use your home theater. If damage is caused by failure to follow instructions, the warranty does not apply.

Safety

Risk of electric shock or fire!

- Never expose the product and accessories to rain or water. Never place liquid containers, such as vases, near the product. If liquids are spilt on or into the product, disconnect it from the power outlet immediately. Contact Philips Consumer Care to have the product checked before use.
- Never place the product and accessories near naked flames or other heat sources, including direct sunlight.
- Never insert objects into the ventilation slots or other openings on the product.
- Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Disconnect the product from the power outlet before lightning storms.
- When you disconnect the power cord, always pull the plug, never the cable.

Risk of short circuit or fire!

 Before you connect the product to the power outlet, ensure that the power voltage matches the value printed on the back or bottom of the product. Never connect the product to the power outlet if the voltage is different.

Risk of injury or damage to the home theater!

- For wall-mountable products, use only the supplied wall mount bracket. Secure the wall mount to a wall that can support the combined weight of the product and the wall mount. Koninklijke Philips Electronics N.V. bears no responsibility for improper wall mounting that results in accident, injury or damage.
- For speakers with stands, use only the supplied stands. Secure the stands to the speakers tightly. Place the assembled stands on flat, level surfaces that can support the combined weight of the speaker and stand.

- Never place the product or any objects on power cords or on other electrical equipment.
- If the product is transported in temperatures below 5°C, unpack the product and wait until its temperature matches room temperature before connecting it to the power outlet.
- Visible and invisible laser radiation when open. Avoid exposure to beam.
- Do not touch the disc optical lens inside the disc compartment.
- Parts of this product can be made of glass. Handle with care to avoid injury and damage.

Risk of overheating!

 Never install this product in a confined space. Always leave a space of at least four inches around the product for ventilation. Ensure curtains or other objects never cover the ventilation slots on the product.

Risk of contamination!

- Do not mix batteries (old and new or carbon and alkaline, etc.).
- Remove batteries if they are exhausted or if the remote control is not to be used for a long time.
- Batteries contain chemical substances, they should be disposed of properly.

Risk of swallowing batteries!

 The product/remote control may contain a coin type battery, which can be swallowed.
 Keep the battery out of reach of children at all times!

Care for your product

- Do not insert any objects other than discs into the disc compartment.
- Do not insert warped or cracked discs into the disc compartment.
- Remove discs from the disc compartment if you are not using the product for an extended period of time.
- Use only microfiber cloth to clean the product.

Care of the environment



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/EC. Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste.

Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.




Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste.

Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.

3 Your home theater

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your home theater at www.philips.com/welcome.


Main unit



- 1 Disc compartment
- Display panel
- ③ ▲ (Open/Close) Open or close the disc compartment, or eject the disc.
- (4) ► II (Play/Pause)
 Start, pause or resume play.
- (5) SOURCE Select an audio or video source for the home theater.
- (6) \circlearrowleft (Standby-On) Switch the home theater on or to standby.

Remote control

This section includes an overview of the remote control.



(1) \circlearrowleft (Standby-On)

- Switch the home theater on or to standby.
- When EasyLink is enabled, press and hold for at least three seconds to switch all connected HDMI CEC compliant devices to standby.

2 ≜ (Open/Close)

Open or close the disc compartment, or eject the disc.

(3) Source buttons

- DISC: Switch to disc source. Access or exit the disc menu when you play a disc.
- AUDIO SOURCE: Select an audio input source.
- RADIO: Switch to FM radio.
- USB: Switch to USB storage device.

(4) Navigation buttons

- Navigate menus.
- In video mode, press left or right to fast backward or fast forward; press up or down to slow backward or slow forward.
- In radio mode, press left or right to search a radio station; press up or down to fine tune a radio frequency.

(5) OK

Confirm an entry or selection.

(6) **⇒** BACK

Return to a previous menu screen.

(7) I ✓ / ►I (Previous/Next)

- Skip to the previous or next track, chapter or file.
- In radio mode, select a preset radio station

Mute or restore volume.

(9) VOL +/-

Increase or decrease volume.

(10) SOUND

Select a sound mode.

(11) Numeric buttons

Select an item to play.

(12) ANGLE

Select video scenes recorded in different camera angels.

(13) REPEAT / PROGRAM

- Select or turn off repeat mode.
- In radio mode, set a radio station.

(14) REPEAT A-B

Mark two points within a chapter or track to repeat play, or turn off the repeat mode.

(15) CREATE MP3/ZOOM

- Access the create MP3 menu.
- Zoom into a video scene or picture.
 Press the Navigation buttons (left/right) to select a zoom factor.

(16) ED SCREEN FIT

Fit the picture format to the TV screen.

(17) SUBTITLE

Select subtitle language for video.

(18) AUDIO SYNC

- Select an audio language or channel.
- Press and hold to access audio delay setting, then press +/- to delay the audio to match the video.

(19) SURR

Select surround sound or stereo sound.

20 **■** (Stop)

Stop play.

(21) ► II (Play/Pause)

Start, pause or resume play.

(22) 1 INFO

Access more play options while playing a disc or a USB storage device.

23) SETUP

Access or exit the setup menu.

24) SLEEP

Switch the home theater to standby after a specified time.

EasyLink controls

With Easylink, you can control your home theater and the TV with the following buttons on your home theater remote control (see 'EasyLink' on page 17).

- O (Standby-On): Press and hold to switch your home theater, TV and the connected devices to standby.
- II (Play/Pause): When a video disc is in the disc compartment, wake up the TV from standby, and then play a disc.

4 Connect your home theater

This section helps you connect your home theater to a TV and other devices.

For information about the basic connections of your home theater and accessories, see the quick start guide. For a comprehensive interactive guide, see www.connectivityguide.philips.com.



Note

- For identification and supply ratings, refer to the type plate at the back or bottom of the product.
- Before you make or change any connections, make sure that all devices are disconnected from the power outlet.


Speakers

Position, connect, and set up your speakers for best surround sound.

Position

Speaker position plays a critical role in setting up a surround sound effect.

For best results, place your speakers and the subwoofer as shown below.





 Surround sound depends on factors such as room shape and size, type of wall and ceiling, windows and reflective surfaces, and speaker acoustics. Experiment with the speaker positions to find the optimum setting for you.

Follow these general guidelines, and then set up your speakers.

- **1** Seating position:
- This is the center of your listening area.

 FRONT CENTER (front center) speaker:
 Place the center speaker directly in front of
 the seating position, either above or below
 your TV. Make sure that it is close to your
- ar height when you are seated.

 FRONT LEFT (front left) and FRONT RIGHT (front right) speakers:

Place the left and right speakers in the front, and equidistant from the center speaker in an arc, so that all the three speakers are at same distance from your seating position. For best effect, point the speakers towards the seating position and place the speakers close to the ear level (when seated).

4 REAR LEFT (rear left) and REAR RIGHT (rear right) speakers:

Place the rear surround speakers to the left and right side of your seating position, either in line with it or slightly behind it. For best effect, point the speakers towards the seating position and place the speakers just above the ear level (when seated).

5 SUBWOOFER (subwoofer):

Place the subwoofer at least one meter to the left or right of the TV. Leave about ten centimeter clearance from the wall.

Connect

Connect your speakers and the subwoofer to your home theater as described in the quick start guide.

Setup

Set up your speakers through the speaker setup menu.


1 Connect your speakers and subwoofer as described in the Quick start guide.

- Turn on your TV, and switch to the correct source for the home theater.
- Press SETUP on your home theater remote control.
- 4 Select [Audio Setup], and then press OK.
- Change the following settings, and then press **OK**.
 - [Speakers Volume]: Set the volume level of each speaker.
 - [Speakers Delay]: Set the delay time for speakers which are placed closer to the seating position in order to obtain equal audio transmission from all the speakers.

Connectors


Connect other devices to your home theater.

Front



- (1) << (USB) Audio, video or picture input from a USB storage device.
- 2 MUSIC iLINK
 Audio input from an MP3 player.

Back connectors



1 AC MAINS

Connect to the power supply.

2 SPEAKERS

Connect to the supplied speakers and subwoofer.

- (3) HDMI OUT Connect to the HDMI input on the TV.
- (4) OPTICAL Connect to an optical audio output on the TV or a digital device.
- (5) VIDEO OUT Connect to the composite video input on the TV
- (6) AUDIO IN-AUX Connect to an analog audio output on the TV or an analog device.
- (7) ANTENNA FM 75 Ω Signal input from an antenna, cable or satellite.

Connect to TV


Connect your home theater to a TV to watch videos. You can listen to audio from TV programs through your home theater speakers. Use the best quality connection available on your home theater and TV.

Option 1: Connect to TV through HDMI

Best quality video

With a standard HDMI connection, you need an additional audio cable to play the audio from the TV through your home theater (see 'Connect audio from TV and other devices' on page 11).

Using a High Speed HDMI cable, connect the HDMI OUT connector on your home theater to the HDMI connector on the TV. The HDMI connector on the TV might be labeled HDMI IN.



- On your TV, turn on HDMI-CEC. For details, see the TV user manual.
 - → When you play a disc on your home theater, the video is automatically displayed on TV and the audio is automatically played on the home theater.
- 3 To play audio from TV programs through your home theater, connect an additional audio cable (see 'Connect audio from TV and other devices' on page 11).
- If audio from the TV does not play automatically on your home theater, set up the audio manually (see 'Set up audio for connected devices' on page 11).



Note

• If your TV has a DVI connector, you can use an HDMI/DVI adapter to connect to TV.


Option 2: Connect to the TV through composite video

Basic quality video

If your TV does not have HDMI connectors, connect your home theater to the TV through a composite connection. A composite connection does not support high-definition video.

With a composite connection, you need an additional audio cable to play the audio from the TV through your home theater (see 'Connect audio from TV and other devices' on page 11).

Using a composite video cable, connect the **VIDEO** connector on your home theater to the composite video connector on the TV. The composite video connector might be labeled AV IN, VIDEO IN, COMPOSITE, or BASEBAND.



On your TV, switch to the correct video input.

To play audio from TV programs through your home theater, connect an additional audio cable (see 'Connect audio from TV and other devices' on page 11).

On your home theater, press **SOURCE** repeatedly to select the correct audio input.

Connect audio from TV and other devices

Play audio from TV or other devices through your home theater.

Use the best quality connection available on your TV, home theater, and other devices.



Note


 The audio connections in this user manual are only recommendations. You can use other connections too.

Option 1: Connect audio through a digital optical cable

Best quality audio

Using an optical cable, connect the **OPTICAL** connector on your home theater to the **OPTICAL OUT** connector on the TV or other device.


The digital optical connector might be labeled **SPDIF, SPDIF OUT,** or **OPTICAL**.



Option 2: Connect audio through analog audio cables

Basic quality audio

Using an analog cable, connect the **AUX** connectors on your home theater to the **AUDIO OUT** connectors on the TV or other device.



5 Use your home theater

This section helps you use the home theater to play media from a wide range of sources.

Before you start

- Make the necessary connections described in the Quick start guide and the user manual.
- Switch the TV to the correct source for the home theater.

Choose sound

This section helps you choose the ideal sound for your video or music.

Sound mode

Select predefined sound modes to suit your video or music.

- Press SOUND repeatedly to select a sound mode.
 - MOVIE: Enjoy a cinematic audio experience, specially enhanced for movies.
 - MUSIC: Recreate the original recording environment of your music, in the studio or at a concert.
 - ORIGINAL: Experience the original sound of your movies and music, without added sound effects.
 - NEWS: Hear every word with optimized speech and clear vocals.
 - GAMING: Enjoy thrilling arcade sounds, ideal for action-packed video games or loud parties.

Surround sound mode

Experience an immersive audio experience with surround sound modes.

- Select SURR repeatedly to select a surround mode.
 - **5CH STEREO**: Enhanced stereo sound. Ideal for party music.
 - MULTI-CH: Traditional 5.1 channels for a more relaxing cinematic experience.
 - STEREO: Two-channel stereo sound. Ideal for listening to music.

Discs

Your home theater can play DVDs, VCDs, and CDs. It can also play discs that you've made at home, such as CD-R discs of photos and music.

What you need

- Audio and video connection between your home theater and the TV.
- An audio or a video disc.

Play discs

- 1 Insert a disc into the home theater.
 - YourTV switches to the correct source and the disc plays automatically. If it does not, press DISC.
- Press the play buttons to control play (see 'Play buttons' on page 12).

Play buttons	
Button	Action
Navigation buttons	Navigate menus.
ОК	Confirm an entry or selection.
► II (Play/ Pause)	Start, pause or resume play.
	Stop play.
I ◀ / ▶ I	Skip to the previous or next track, chapter or file.
44/	Fast backwards or fast forwards. Press repeatedly to change the search speed.
Navigation buttons (left/ right)	Rotate the picture clockwise or counter-clockwise.
Navigation buttons (up/down)	Flip the picture vertically or horizontally.
SUBTITLE	Select subtitle language for video.
DISC	Access or exit the disc menu.
AUDIO SYNC	Select an audio language or channel.
SCREEN FIT	Fit the picture format to the TV screen.
ZOOM	Zoom into a video scene or picture.

Button	Action
REPEAT	Select or turn off repeat mode.
REPEAT A-B	Mark two points within a chapter or track to repeat play, or turn off the repeat mode.
ANGLE	Select video scenes recorded in different camera angels.
1 INFO	Access the advanced options when you play your audio, video, or media files (see 'Audio, video, and picture options' on page 14).

Display menu for VCD and SVCD

Display the content menu on VCD and SVCD discs.

- 1 Press SETUP.
- 2 Select [Preference Setup], and then press OK.
- 3 Select [PBC] > [On], and then press OK.



Note

- To skip the content menu, select [Off].
- While playing a VCD/SVCD, you can press DISC to turn off or on the PBC (playback control).

Display menu for MP3/JPEG

You can choose how you want the MP3 contents to display.

- 1 Press SETUP.
- 2 Select [Preference Setup], and then press OK.
- 3 Select [MP3/JPEG Display], and then press OK
- 4 Select the following options, then press **OK**.
 - **[View Folders]**: Display the MP3 folders.
 - **[View Files]**: Display the MP3 files.

Synchronize picture and sound

If the audio and video are not synchronized, delay the audio to match the video.

- 1 Press SETUP.
- 2 Select [Audio Setup], and then press OK.
- **3** Select [Audio Sync], and then press **OK**.
- 4 Press the Navigation buttons (left/right) to synchronize the audio with the video.
- **5** Press **OK** to confirm.



Note

 Press and hold AUDIO SYNC on the remote control for quick access to the audio sync setup menu.

USB storage devices

Enjoy pictures, audio and video on a USB storage device.

What you need

- A USB storage device that is formatted for FAT, and complies with the Mass Storage Class.
- A USB extension cable, if the USB storage device does not fit into the connector



Note

 You can use digital cameras connected by USB if they can play the files without using a special computer program.

Play files

- 1 Connect the USB storage device to the home theater.
- 2 Press USB.
 - → A content browser is displayed.
- 3 Select a file, and then press OK.
- 4 Press the playback buttons to control play (see 'Play buttons' on page 12).

DivX

Play DivX videos from:

- a disc (see 'Discs' on page 12),
- a USB storage device (see 'USB storage devices' on page 13).

VOD code for DivX

Before you purchase DivX videos and play them on your home theater, register the home theater on www.divx.com using the DivX VOD code.

1 Press SETUP.

Select [General Setup], and then press OK.
 Select [DivX(R) VOD Code], and then press OK.

→ The DivXVOD registration code for your home theater is displayed.

Subtitles

If your video has subtitles in multiple languages, select a subtitle language.

1 While playing video, press **SUBTITLE** to select a language.



Note

- Make sure that the subtitle file has the same name as the video file. For example, if the video file is named 'movie.avi', save the subtitle file as 'movie.srt' or 'movie.sub'.
- Your home theater can play subtitle files in the following formats: .srt, .sub, .txt, .ssa, .ass, smi, and .sami. These files do not appear in the file navigation menu.
- If the subtitles do not appear correctly, change the character set.

Subtitle character set

If the subtitles do not appear correctly, change the character set that supports the DivX subtitle.

1 Press © SETUP.

Select [Preference Setup], and then press OK.

3 Select [DivX Subtitle], and then press OK.

Select a character set, and the press **OK**.

Character Set	Language
[Standard]	English, Albanian, Danish, Dutch, Finnish, French, Gaelic, German, Italian, Kurdish (Latin), Norwegian, Portuguese, Spanish, Swedish and Turkish
[Central Europe]	Albanian, Croat, Czech, Dutch, English, German, Hungarian, Irish, Polish, Romanian, Slovak, Slovene and Sorbian
[Cyrillic]	Bulgarian, Belorussian, English, Macedonian, Moldavian, Russian, Serbian and Ukrainian
[Greek]	Greek
[Hebrew]	Hebrew
[Chinese(Simp)]	Simplified Chinese

Audio, video, and picture options

Use advanced features when you play audio, video, or media files from a disc or a USB storage device.

Audio options

- 1 Press I INFO repeatedly to cycle through the following options:
 - Show the current track information and time.
 - [Off]: Press Navigation buttons (left/right) to select a repeat mode.
 - [Disc Go To:]: Skip to a specific part of the disc by entering the disc time.
 - [Track Go To:]: Skip to a specific part of the track by entering the track time.
 - [Select Track:]: Select a specific track.

Video options

- 1 Press © INFO.
 - → The video options menu is displayed.
- Press the **Navigation buttons** and **OK** to select and change:
 - [Title]: Select a specific title.
 - [Chapter]: Select a specific chapter.
 - [Track]: Select a specific track (for VCD/SVCD only).
 - [Audio]: Select audio language for video.
 - [Subtitle]: Select subtitle language for video.
 - [Angle]: Select video scenes recorded in different camera angels.
 - **[TT Time]**: Skip to a specific part of the video by entering the title time.
 - **[Ch Time]**: Skip to a specific part of the video by entering the chapter time.
 - [Disc Time]: Skip to a specific part of the video by entering the disc time (for VCD/SVCD only).
 - [Track Time]: Skip to a specific part of the video by entering the track time (for VCD/SVCD only).
 - [Repeat AB]: Mark two points within a chapter or track to repeat play, or turn off the repeat mode.
 - **[Preview]**: Select a content preview for disc.
 - [Repeat]: Select a repeat mode.
 - [Time Disp.]: Select the information of time display.

Picture options

- 1 Press I INFO to access picture preview mode.
 - → 12 thumbnail pictures are displayed.
- Press I◀/►I to go to previous or next preview page.
- Press the Navigation buttons and OK to select a picture.

Slideshows

While playing audio, access fun features such as picture and musical slideshows.

Picture slideshows

View a slideshow of your pictures stored in your disc or a USB storage device.

- Select a picture from a disc or USB storage device, and then press ►II.
- 2 Press to stop the slideshow.

Musical slideshows

Create a musical slideshow to play music and pictures at the same time.

- 1 Select a music track, and then press **OK**.
- Press SACK, and go to the picture folder.
- 3 Select a picture, and then press ► (Play) to start the slideshow.
- **4** Press to stop slideshow.
- **5** Press again to stop music.

Radio

Listen to FM radio on your home theater, and store up to 40 radio stations.

What you need

FM antenna.



Note

- AM and digital radio are not supported.
- If no stereo signal is detected, you are prompted to install the radio stations again.
- For the best reception, place the antenna away from the TV or other sources of radiation.

Tune stations

- 1 Connect the FM antenna as described in the Quick start guide.
- 2 Press RADIO.
 - → If you have already installed the radio stations, the last channel that you listened to is played.
 - If you have not installed any radio stations, the message AUTO INSTALL... PRESS PLAY appears on the display panel. Press ▶ (Play).
- 3 Press the following buttons to listen or to change radio stations:

Button	Action
 	Select a preset radio station.
Navigation buttons (left/right)	Search for a radio station.
Navigation buttons (up/down)	Fine tune a radio frequency.
	Press to stop the installation of radio stations. Press and hold to erase the preset radio station.
PROGRAM	Manual: Press once to access program mode, and press again to store the radio station. Automatic: Press and hold for three seconds to reinstall the radio stations.

Listen to radio

- 1 Press RADIO.
 - To listen to a preset station, press I
 or ►I.
 - To search for a radio station, and then listen, press Navigation buttons (left/ right).
- 2 Press +/- (Volume) to change the volume.

MP3 player

Connect your MP3 player to play your audio files or music.

What you need

- An MP3 player.
- A 3.5mm stereo audio cable.

Play music

- Connect the MP3 player to the home theater as described in the Quick start guide.
- Press AUDIO SOURCE repeatedly until 'MUSIC I-LINK' appears on the display panel.
- **3** Press the buttons on the MP3 player to select and play audio files or music.

Create MP3 files

Use your home theater to convert audio CDs into MP3 files.

What you need

- An audio disc.
- A USB storage device
- 1 Connect a USB storage device to the home theater.
- 2 Play your audio CD (CDDA/HDCD).
- Press CREATE MP3.
 - → A confirmation message is displayed.
- 4 Select [Yes], and then press OK.
 - → The create MP3 screen is displayed. The right panel contains MP3 settings and the left panel shows the audio tracks.

CREATE MP3			
OPTI	ONS	TRACK	
Speed	Normal	O Track01	04:14
Bitrate	128kbps	O Track02	04:17
CRT ID3	Yes	O Track03	03:58
Device	USB1	O Track04	04:51
Device	0361	O Track05	03:53
SUMMARY		O Track06	04:09
Select Track	. 0	O Track07	04:38
Time	00:00	,	•
Start	Exit	Select All	Deselect All

- Fress the Navigation buttons and OK to select and change:
 - [Speed]: Select the write-to-file speed.
 - [Bitrate]: Select the conversion quality.
 - [CRT ID3]: Copy the tracks information when converting to MP3 files
 - [Device]: Select the USB storage device which you use to store the MP3 files.
- 6 Navigate to the right panel, and then select the audio tracks and press **OK**.
 - To select all tracks, navigate to [Select All], and then press OK.
- Select [Start], and then press OK to start the MP3 conversion.
 - → A new folder which contains the MP3 files is created in the USB storage device.

 To exit the menu, select [Exit], and then press OK.



Note

- When the conversion is in process, do not press any buttons.
- DTS CDs and copy-protected CDs cannot be converted.
- Write-protected or password-protected USB storage device cannot be used to store MP3 files.

EasyLink

The home theater supports Philips EasyLink, which uses the HDMI-CEC (Consumer Electronics Control) protocol. EasyLink-compliant devices that are connected through HDMI can be controlled by a single remote control.

Philips does not guarantee 100% interoperability with all HDMI-CEC devices.

What you need

- HDMI-CEC compliant devices.
- An HDMI connection between the connected devices.

Switch on

- On the TV and other connected devices, turn on the HDMI-CEC operations. For details, see the manual of the TV or other devices.
- 2 Press © SETUP.
- 3 Select [General Setup], and then press OK.
- 4 Select [EasyLink Setup] > [EasyLink], and then press OK.
- 5 Select [On], and then press OK.

Control devices

Control the home theater and the other connected HDMI-CEC compliant devices with a single remote control.

One-touch play

If you enable One-touch play, the TV automatically switches to the correct channel when you play a disc in your home theater.

One-touch standby

When you press and hold \circ (Standby) on the remote control, the home theater and all the connected HDMI-CEC devices (that support one-touch standby) switch to the standby mode.

If one-touch standby is enabled on your home theater, you can switch to standby with the remote control of the TV or other HDMI-CEC devices.

6 Change settings

This section helps you to change the settings of your home theater:



Caution

 Most of the settings are already configured with the best value for your home theater.
 Unless you have a reason to change a setting, it is best to leave it at the default value.



Note

- · You cannot change a setting that is grayed out.
- To return to the previous menu, press ⇒ BACK. To exit the menu, press © SETUP.

Picture

Change the picture settings to suit your preferences.



Note

 The best setting is automatically selected for the TV. If you change the setting, make sure that the TV supports the new settings.

Picture settings and format

1 Press SETUP.

Select [Video Setup], and then press OK.

Change the following settings, and then press **OK**:

- [TV System]: For TV supported video format.
- [TV Display]: For TV picture display format
- [Picture Settings]: Predefined color settings.

Picture resolution

To enjoy high definition HDMI video output, set the HDMI video settings that best match up with your TV capability.

1 Press SETUP.

Select [Video Setup], and then press OK.

3 Select [HDMI Setup], and then press OK.

4 Change the following settings, and then press **OK**:

- [Wide Screen Format]: For 16:9 wide screen TV display setting.
- [HDMI Video]: HDMI resolution.

High definition picture

Support high definition JPEG pictures.

1 Press SETUP.

2 Select [Video Setup], and then press OK.

3 Select [HD JPEG] > [On], and then press OK.

Sound

Change the sound settings to suit your preference.

HDMI audio

HDMI audio is automatically down-mixed to two channel for TV speakers. If you do not want to output audio through your TV, disable the HDMI audio.

1 Press SETUP.

2 Select [Audio Setup], and then press OK.

Select [HDMI Audio] > [Off], and then press OK.

Language

Select a language for the home menu, audio, and subtitles.

Home menu

1 Press SETUP.

2 Select [General Setup], and then press OK.

3 Select [OSD Language], and then press OK.

4 Select a menu language for your home theater, and then press **OK**.

Disc audio

1 Press SETUP.

2 Select [Preference Setup], and then press OK.

3 Select [Audio], and then press OK.

4 Select an audio language for discs, and then press **OK**.



Note

- If your preferred disc language is not available, select [Others] from the list, and enter the 4-digit language code found at the end of this user manual (see 'Language code' on page 999).
- If you select a language that is not available on a disc, the home theater uses the default language of the disc.

Disc subtitle

1 Press SETUP.

Select [Preference Setup], and then press OK.

3 Select [Subtitle], and then press OK.

4 Select a subtitle language for discs, and then press **OK**.

Disc menu

1 Press SETUP.

Select [Preference Setup], and then press OK.

3 Select [Disc Menu], and then press OK.

4 Select a menu language for discs, and then press **OK**.



Note

- If your preferred disc language is not available, select [Others] from the list, and enter the 4-digit language code found at the end of this user manual (see 'Language code' on page 999).
- If you select a language that is not available on a disc, the home theater uses the default language of the disc.

Parental control

Restrict access to discs.

Password

You can set or change your password to play a restricted disc.

1 Press 🗈 SETUP.

2 Select [Preference Setup], and then press OK.

3 Select [Password], and then press OK.

→ A change password menu is displayed.

Follow the instructions on the TV to set or change password.

• If you do not have a password or you have forgotten, enter **0000**.

5 Press OK.

Ratings

Some discs are recorded with ratings according to age. You can set up your home theater to play only discs with an age rating lower than your child's age.

1 Press SETUP.

2 Select [Preference Setup], and then press OK.

3 Select [Parental], and then press OK.

A message prompts you to enter the password.

Enter the password with the **Numeric buttons**.

Select an age rating, and then press **OK**.

• To play all discs irrespective of the rating, select level 8 or [Off].

Lock disc

To restrict access to discs that are not encoded with ratings and parental control, lock the disc manually. You can lock upto 20 discs on your home theater.

1 While playing a disc, press © SETUP.

Select [General Setup], and then press OK.

Select [Disc Lock] > [Lock], and then press OK.

→ A message prompts you to enter the password.

4 Enter the password with the Numeric buttons.

- → The disc is locked.
- → To play the locked disc, enter the password.

Energy saving

Save energy by changing the following settings.

Auto standby

When playing a disc or a USB storage device, automatically switch your home theater to standby if:

- it is in pause or stop mode, and
- no button is pressed for 30 minutes.

Press SETUP.

Select [General Setup], and then press OK.
Select [Auto Standby] > [On], and then press OK.

Sleep timer

Set timers to switch the home theater to standby after a specified time.

1 Press SETUP.

Select [General Setup], and then press OK.

Select [Sleep Timer], and then press OK.

Select the duration of the sleep timer.

The sleep timer can be set up to 60 minutes. If the sleep timer is set to [Off], it switches off.

5 Press **OK** to activate.

→ The home theater switches to standby after the specified time.

Screen saver

Automatically switch your home theater to screen saver mode if:

- it is in pause or stop mode, and
- no button is pressed for 10 minutes.
 - Press 🗈 SETUP.
- 2 Select [General Setup], and then press OK.
- 3 Select [Screen Saver] > [On], and then press OK.

Display panel

Change the brightness of the home theater display panel.

- 1 Press SETUP.
- 2 Select [General Setup], and then press OK.
- 3 Select [Display Dim], and then press OK.
- **4** Select the brightness, and then press **OK**.

Apply factory settings

Reset your home theater to the default settings. You cannot reset the parental control settings.

- 1 Press © SETUP.
- 2 Select [Preference Setup], and then press OK.
- 3 Select [Default], and then press OK.
- 4 Select [Ok], and then press OK.

7 Update software

To continue to get the best features and support for your home theater, update the software regularly. Compare the version of your current software with the latest version on www.philips.com/support.

Check software version

- 1 Press SETUP.
- 2 Select [Preference Setup], and then press OK.
- Select [Version Info.], and then press OK.→ The software version is displayed.

Update software through USB or CD-R

What you need

- A CD-R or a USB flash drive with at least 75MB of memory. The USB flash drive must be FAT formatted. Do not use a USB hard drive.
- A computer with Internet access.
- An archive utility that supports the ZIP file format (for example, WinZip® for Microsoft® Windows® or Stufflt® for Macintosh®).

Step 1: Download the latest software

- 1 Connect a USB flash drive or insert a CD-R to your computer.
- 2 In your web browser, go to www.philips. com/support.
- 3 At the Philips Support website, find your product and locate the Software and drivers.
 - → The software update is available as a zip file.
- 4 Save the zip file in the root directory of your USB flash drive or CD-R.
- 5 Use the archive utility to extract the software update file in the root directory.
 - → The files are extracted under the UPG_ALL folder of your USB flash drive or CD-R.

Remove the USB flash drive or CD-R from your computer.

Step 2: Update the software



Warning

- If you use a USB flash drive, make sure that there is no disc in the disc compartment, and the disc compartment is closed.
- 1 Connect the USB flash drive or insert the CD-R to your home theater.
- 2 Switch your TV to the correct source for your home theater.
- Follow the instructions on the TV to complete the update.
 - When the software update is complete, the home theater automatically switches off and restarts. If it does not, disconnect the power cord for a few seconds, and then reconnect it



Vote

 When the software update is in progress, do not turn off the power, or remove the USB flash drive or CD-R.

21

8 Product specifications



Specifications and design are subject to change without notice.

Region codes

The type plate on the back or bottom of the home theater shows which regions it supports.

Country	DVD
Europe, United Kingdom	
Asia Pacific, Taiwan, Korea	
Latin America	
Australia, New Zealand	
Russia, India	
China	

Media formats

 DVD-Video, DVD+R/+RW, DVD-R/-RW, DVD+R/-R DL, CD-R/CD-RW, Audio CD, Video CD/SVCD, Picture files, MP3 media, WMA media, DivX media, USB storage device

File formats

- Audio: .mp3, .wma
- Video: .avi, .divx, .mpg, .mpeg,
- Picture: .jpg, .jpeg

Amplifier

- Total output power: 300W RMS (30% THD)
- Frequency response: 20 Hz-20 kHz / ±3 dB
- Signal-to-noise ratio: > 65 dB (CCIR) / (A-weighted)
- Input sensitivity:
 - AUX: 2 V
 - Music iLink: 1 V

Video

- Signal system: PAL / NTSC
- HDMI output: 480i/576i, 480p/576p, 720p, 1080i, 1080p

Audio

- S/PDIF Digital audio input:
 - Optical: TOSLINK
- Sampling frequency:
 - MP3: 32 kHz, 44.1 kHz, 48 kHz
 - WMA: 44,1 kHz, 48 kHz
- Constant bit rate:
 - MP3: 32 kbps 320 kbps
 - WMA: 64 kbps 192 kbps

Radio

- Tuning range:
 - Europe/Russia/China: FM 87.5-108 MHz (50 kHz)
 - Asia Pacific/Latin America: FM 87.5-108 MHz (50/100 kHz)
- Signal-to-noise ratio: FM 50 dB
- Frequency response: FM 200 Hz-12.5 kHz / ±6 dB

USB

- Compatibility: Hi-Speed USB (2.0)
- Class support: USB Mass Storage Class (MSC)
- File system: FAT16, FAT32
- Maximum memory support: < 160 GB

Main unit

- Power supply:
 - Europe/China/Russia/India: 220-240V~, 50 Hz

- Latin America/Asia Pacific: 110-240V~, 50-60 Hz
- Power consumption: 55 W
- Standby power consumption: ≤ 0.9 W
- Dimensions (WxHxD): 360 x 58 x 325 mm
- Weight: 2.3 kg

Subwoofer

- Output power: 50 W RMS (30% THD)
- Impedance: 4 ohm
- Speaker drivers: 133 mm (5.25") woofer
- Dimensions (WxHxD): 160 x 265 x 265 mm
- Weight: 2.50 kg
- Cable length: 3 m

Speakers

Center speaker:

- Output power: 50 W RMS (30% THD)
- System: 1 x 63.5 mm (2.5") full range
- Speaker impedance: 4 ohm
- Speaker drivers: 1 x 63.5 mm (2.5") woofer
- Dimensions (WxHxD): 159 x 84.5 x 80 mm
- Weight: 0.35 kg
- Cable length: 2 m

Front/Rear speaker:

- Output power: 4 x 50 W RMS (30% THD)
- Speaker impedance: 4 ohm
- Speaker drivers: 1 x 63.5 mm (2.5") full range
- Dimensions (WxHxD): 84.5 x159 x 80mm
- Weight (front): 0.35 kg/each
- Weight (rear): 0.35 kg/each
- Cable length (front): 3 m
- Cable length (rear): 7 m

Remote control batteries

2 x AAA-R03-1.5 V

Laser

- Type: Semiconductor laser GaAlAs (CD)
- Wave length: 645 665 nm (DVD), 770 -800 nm (CD)
- Output power: 6 mW (DVD), 7 mW (VCD/CD)
- Beam divergence: 60 degrees.

9 Troubleshooting



Warning

 Risk of electric shock. Never remove the casing of the product.

To keep the warranty valid, never try to repair the product yourself.

If you have problems using this product, check the following points before you request service. If you still have a problem, register your product and get support at www.philips.com/welcome.

Main unit

The buttons on the home theater do not work.

 Disconnect the home theater from the power supply for a few minutes, then reconnect.

Picture

No picture.

- Make sure that the TV is switched to the correct source for the home theater.
- If this happens when you change the TV system, press ≜ to open the disc compartment, and then 3 on the remote control to restore the default TV system..

No picture on a TV connected through HDMI.

- Make sure that the HDMI cable is not faulty.
 If it is faulty, replace it with a new cable.
- Press ≜ to open the disc compartment, and then 1 on the remote control to restore the default picture resolution.
- Wait for 10 seconds for auto recovery, or change the HDMI video setting (see 'Picture resolution' on page 18).

Disc does not play high-definition video.

- Make sure that the disc contains highdefinition video.
- Make sure that the TV supports highdefinition video.
- Use an HDMI cable to connect to the TV.

Sound

No sound from home theater speakers.

- Connect the audio cable from your home theater to your TV or other devices (see 'Connect audio from TV and other devices' on page 11).
- Set up the audio for the connected device (see 'Set up audio for connected devices' on page 11).
- Reset your home theater to its factory settings (see 'Apply factory settings' on page 20), then switch it off and switch on again.
- On your home theater, press **SOURCE** repeatedly to select the correct audio input.

Distorted sound or echo.

If you play audio from the TV through the home theater, make sure that the TV is

Audio and video are not synchronized.

1) Press and hold AUDIO SYNC. 2) Press +/- within five seconds to synchronize the audio with the video.

Play

Cannot play a disc.

- Clean the disc.
- Make sure that the home theater supports the type of disc (see 'Media formats' on page 22).
- Make sure that the home theater supports the region code of the disc (see 'Region codes' on page 22).
- If the disc is a DVD±RW or DVD±R disc, make sure that it is finalized.

Cannot play a DivX file.

- Make sure that the DivX file is encoded according to the 'Home Theater Profile' with the DivX encoder.
- Make sure that the DivX file is complete.

DivX subtitles do not display correctly.

- Make sure that the subtitle file name is the same as the movie file name (see 'Subtitles' on page 14).
- Select the correct character set: 1) Press **SETUP.** 2) Select [Preference Setup] > [DivX Subtitle]. 3) Select the supported character set. 4) Press OK.

Cannot read the contents of a USB storage device.

- Make sure that the format of the USB storage device is compatible with the home theater.
- Make sure that the file system on the USB storage device is supported by the home theater.

'No entry' or 'x' sign appears on the TV.

The operation is not possible.

EasyLink does not work.

Make sure that the home theater is connected to a Philips brand EasyLink TV, and the EasyLink option is on (see 'EasyLink' on page 17).

When you switch on the TV, the home theater automatically switches on.

This behavior is normal when you are using Philips EasyLink (HDMI-CEC). To make the home theater work independently, switch off EasyLink.

10 Index

A	
amplifier	22
audio	
HDMI audio	18
predefined modes	12
quality	11 18
settings source	11
speaker setup	9
specifications	22
audio language	19
audio options	14
auto standby	20
В	
brightness	20
C	
care	
environment	6
product	5
connect	44
audio (analog cable)	11 11
audio (optical cable - digital) audio from TV and other devices	11
speakers	9
TV (Composite)	10
TV (HDMI)	10
connectors	
front connectors	9
control	
disc play	12
Easylink (HDMI-CEC)	8 6
main unit parental control	6 19
radio	15
copyright protection	4
create MP3	16

D	
disable	
HDMI-CEC	17
discs	
audio language	19
audio options	14
control buttons	12
DivX	14
lock/unlock	20 19
menu language options	12
picture	15
play	12
subtitle	19
synchronize picture and sound	13
time search	15
titles	15
display	
MP3/JPEG menu	13
VCD/SVCD menu	13
display panel	6
DivX	4.
character set	1 <u>-</u> 1 <u>-</u>
subtitles VOD code	1-
VOD code	'
E III (IIDMI CEC)	
EasyLink (HDMI-CEC) control buttons	8
one-touch play	17
one-touch standby	17
play audio	17
enable	.,
auto standby	20
HDMI-CEC [']	17
screen saver	20
energy	
auto standby	20
brightness	20
screen saver	20
sleep timer	20
F	
factory settings	20
FM antenna	Ç

		P	
HDMI		parental control	
audio	18	lock disc	20
video settings	18	password	19
HDMI-CEC	17	ratings	19
TIDI II-CEC	17	.	19
		password	17
1		Philips Easylink picture	17
language		high resolution JPEG	18
audio	19	options	15
disc menu	19	rotate	15
onscreen menu	19	settings	18
subtitle	19	slideshows	15
Subtitie	17	troubleshooting	23
		zoom	15
M		picture options	15
main unit		play	15
overview	6	discs	12
specifications	22	MP3	16
troubleshooting	23	radio	22
5	9	slideshows	15
manually setup speakers media formats	22	troubleshooting	24
MP3	22	USB	13
	9	position	15
connector create MP3	16	connectors	9
	13	position	É
display contents	16	preference	
play	16	audio	18
		auto standby	20
Ν		change password	19
	40	disc menu	19
night mode	12	display panel	20
		menu language	19
		screen saver	20
O	47	sleep timer	20
one-touch play	17	subtitle	19
one-touch standby	17	product specifications	22
options	4.5	product specifications	22
picture	15		
overview	0	R	
connectors	9	radio	
HDMI-CEC	17	control buttons	15
main unit	6	FM antenna	9
remote control	7	listen to radio	16
settings	18	specifications	22
speaker setup	9	tune stations	15
			19
		ratings	
		recycling	22
		region codes	22
		remote control	าร
		batteries	23
		overview	/ 14
		repeat	14

5		1
safety		time search
disposal	6	titles
use of the product	5	trademarks
screen saver	20	troubleshooting
settings		connection
audio	18	main unit
auto standby	20	picture
default	20	play
disc language	19	sound
HDMI audio	18	
HDMI video	18	-
HDMI-CEC	17	U
menu language	19	update software
parental rating	19	check current version
password	19	update
picture	18	USB
power	20	format
restore	20	USB storage device
screen saver	20	options
sleep timer	20	play
subtitle language	19	• •
video	18	specifications
setup speakers	10	
manually	9	V
sleep timer	20	video
slideshows	20	
musical	15	picture settings
picture	15	synchronize picture and sound
software	13	VOD code for DivX
check current version	21	video formats
update	21	video options
sound	21	VOD code for DivX
predefined sound mode	12	
surround sound	12	
	13	
synchronize picture and sound	24	
troubleshooting speakers	27	
connect	9	
	9	
manual setup	8	
position	9	
setup	23	
specifications		
surround sound	12	
subtitle	14	
character set		
language	19	
subwoofer	23	
specifications	23 13	
synchronize picture and sound	13	

Language Code

Abkhazian	6566	Inupiaq	7375	Pushto	8083
Afar	6565	Irish	7165	Russian	8285
Afrikaans	6570	Íslenska	7383	Quechua	8185
Amharic	6577	Italiano	7384	Raeto-Romance	8277
Arabic	6582	lvrit	7269	Romanian	8279
Armenian	7289	Japanese	7465	Rundi	8278
Assamese	6583	Javanese	7486	Samoan	8377
Avestan	6569	Kalaallisut	7576	Sango	8371
Aymara	6589	Kannada	7578	Sanskrit	8365
Azerhaijani	6590	Kashmiri	7583	Sardinian	8367
Bahasa Melayu	7783	Kazakh	7575	Serbian	8382
Bashkir	6665	Kernewek	7587	Shona	8378
Belarusian	6669	Khmer	7577	Shqip	8381
Bengali	6678	Kinyarwanda	8287	Sindhi	8368
Bihari	6672	Kirghiz	7589	Sinhalese	8373
Bislama	6673	Komi	7586	Slovensky	8373
Bokmål, Norwegian	7866	Korean	7579	Slovenian	8376
Bosanski	6683	Kuanyama; Kwanyama	7574	Somali	8379
Brezhoneg	6682	Kurdish	7585	Sotho; Southern	8384
Bulgarian	6671	Lao	7679	South Ndebele	7882
Burmese	7789	Latina	7665	Sundanese	8385
Castellano, Español	6983	Latvian	7686	Suomi	7073
Catalán	6765	Letzeburgesch;	7666	Swahili	8387
Chamorro	6772	Limburgan; Limburger	7673	Swati	8383
Chechen	6769	Lingala	7678	Svenska	8386
Chewa; Chichewa; Nyanja	a 7889	Lithuanian	7684	Tagalog	8476
中文	9072	Luxembourgish;	7666	Tahitian	8489
Chuang; Zhuang	9065	Macedonian	7775	Tajik	8471
Church Slavic; Slavonic	6785	Malagasy	777	Tamil	8465
Chuvash	6786	Magyar	7285	Tatar	8484
Corsican	6779	Malayalam	7776	Telugu	8469
âesky	6783	Maltese	7784	Thai	8472
Dansk	6865	Manx	7186	Tibetan	6679
Deutsch	6869	Maori	7773	Tigrinya	8473
Dzongkha	6890	Marathi	7782	Tonga (Tonga Islands)	8479
English	6978	Marshallese	7772	Tsonga	8483
Esperanto	6979	Moldavian	7779	Tswana	8478
Estonian	6984	Mongolian	7778	Türkçe	8482
Euskara	6985	Nauru	7865	Turkmen	8475
ďΪËÓÈÎį	6976	Navaho; Navajo	7886	Twi	8487
Faroese	7079	Ndebele, North	7868	Uighur	8571
Français	7082	Ndebele, South	7882	Ukrainian	8575
Frysk	7089	Ndonga	787	Urdu	8582
Fijian	7074	Nederlands	7876	Uzbek	8590
Gaelic; Scottish Gaelic	7168	Nepali	7869	Vietnamese	8673
Gallegan	7176	Norsk	7879	Volapuk	8679
Georgian	7565	Northern Sami	8369	Walloon	8765
Gikuyu; Kikuyu	7573	North Ndebele	7868	Welsh	6789
Guarani	7178	Norwegian Nynorsk;	7878	Wolof	8779
Gujarati	7185	Occitan; Provencal	7967	Xhosa	8872
Hausa	7265	Old Bulgarian; Old Slavonic	6785	Yiddish	8973
Herero	7290	Oriya	7982	Yoruba	8979
Hindi	7273	Oromo	7977	Zulu	9085
Hiri Motu	7279	Ossetian; Ossetic	7983		
Hrwatski	6779	Pali	8073		
Ido	7379	Panjabi	8065		
Interlingua (International	1)7365	Persian	7065		
Interlingue	[^] 7365	Polski	8076		
Inuktitut	7385	Português	8084		

