

Philips  
Portable DVD Player



PET725



## DVD and DivX® movies on the go

Zero Bright Dot™ for perfect viewing

Immerse in DVD movies on the go with the PET725 with 17.8 cm (7") color LCD display and Philips Zero Bright Dot™ for optimal screen quality. Enjoy DivX®, MPEG4 movies, MP3/WMA-CD music, or playback JPEG still images. Travel bag included.

### Immerse in AV entertainment on the go

- Play DVD, DVD+/-R and DVD+/-RW, (S)VCD, DivX® & MPEG4 movies
- Play MP3/WMA-CD, CD and CD-RW
- Share JPEG image files with Picture CD

### Comfortable viewing anywhere

- Zero Bright Dot™ screen for optimal screen quality
- 17.8 cm (7") TFT color LCD display for high quality viewing
- Watch movies in 16:9 widescreen format
- Built-in quality stereo speakers

### For ultimate convenience

- Contemporary precision design with piano-white top cover
- Up to 4-hour playback with rechargeable battery\*
- Car adaptor and slim remote control
- Travel bag included
- Share entertainment fun with dual headphone jacks

# PHILIPS

# Highlights

## Play DVD, DivX and MPEG4

With DivX® support, you are able to enjoy DivX® encoded videos in the comfort of your living room. The DivX® media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, memory cards and DVD-video. DivX® CDs can be played back on selected DVD

players, DVD Recorders and Home Theater Systems.

## Zero Bright Dot™ screen

Enjoy highest-quality images that are free from annoying blank spots on the LCD screen. LCD displays commonly have imperfections, termed as 'bright dots' by the LCD industry. A limited number of bright dots were once considered

an inevitable side effect of LCD mass production. With Philips' strict quality control procedures used in our Portable DVD Players, our LCD displays are produced with zero tolerance for bright dots. Select Portable DVD Players come with Philips Zero Bright Dot™ Policy to guarantee optimal screen quality.



# Specifications

## Picture/Display

- Display screen type: LCD TFT
- LCD panel type: Anti-glare polarizer
- Diagonal screen size (inch): 7 inch
- Resolution: 480(w)x234(H)x3(RGB)
- Brightness: 200 cd/m<sup>2</sup>
- Contrast ratio (typical): 250:1
- Effective viewing area: 154.1x86.6mm
- Pixel pitch: 0.107(w)x0.370(H)mm
- Response time (typical): 30 ms

## Sound

- Output Power: 250mW RMS(built-in speakers)
- Output power (RMS): 10mW RMS(earphone)
- Signal to noise ratio: >80dB(earphone), >62dB(built-in speakers)

## Video Playback

- Playback Media: DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, MP3-CD, CD-R/CD-RW, WMA, DVD+R/+RW, CD
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, OSD, Repeat, Shuffle Play, Slow Backward, Slow Forward, Zoom
- Video disc playback system: NTSC, PAL
- Compression formats: MPEG4, Divx

## Audio Playback

- Compression format: Dolby Digital, MP3, WMA
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- File systems supported: ISO-9660, Joliet
- MP3 bit rates: 32 - 320 kbps
- WMA bit rates: 32 - 192 kbps

## Connectivity

- Audio Output - Digital: Coaxial (cinch)
- DC in: 9V
- AV output: Composite (CVBS) x1
- AV input: Composite (CVBS) x1
- Headphone jack: 3.5mm Stereo Headphone x 2

## Convenience

- Shock proof
- Battery charging indication

## Accessories

- Battery pack: DV 7.4V, Li-ion rechargeable batteries
- AC/DC Adaptor: (110-240v, 50/60Hz)
- Cables: 1 x AV Cables
- Car kit: cigarette outlet adaptor, 12vDC
- Included accessories: Travel pouch
- Remote control: RC810(credit card style, 38 keys)
- User Manual: Printed Eng/Frn/Spn/Por

## Dimensions

- Master carton dimensions: 350 x 251 x 374 mm
- Master carton quantity: 3
- Master carton weight: 8.4 kg
- Packaging dimensions (W x H x D): 355 x 225 x 110 mm
- Packaging type: D-box
- Product dimensions (W x H x D): 193 x 33 x 170 mm
- Product weight: 0.85 kg



Issue date 2014-02-06

Version: 1.0.6

12 NC: 8670 000 26238  
EAN: 87 12581 30777 6

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.