



Philips  
Micro Hi-Fi System

CD playback  
wall-mountable

MC235B

## Unique Style — Great Sound — Wall Mountable

Trendy and progressive, unique innovation and style appeals to you. And so will the vividly chic MC235B with dynamic sound performance packed in a sleek design that can also be wall mounted.

### Enrich your sound experience

- Play CD, CD-R and CD-RW discs
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2 x 5 W RMS/2 x 10 W music power/400 W PMPO

### Start the day your way

- Wake-Up and Sleep Timer
- Digital tuning with 40 pre-set stations for extra convenience

### Design that blends into your interior

- Super sleek and flexible wall-mountable design
- Elegant design with motorised sliding front door

# PHILIPS

# Specifications

## Sound

- Output Power: 2 x 10 W Music Power
- Output power (RMS): 2 x 5 W
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

## Loudspeakers

- Main Speaker: 3" woofer, Bass Reflex Speaker System, Piezo tweeter

## Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Repeat/one/all/programme, Shuffle Play, 20-Track Programmable
- Loader Type: Front, Motorised

## Tuner/Reception/Transmission

- Auto digital tuning
- Tuner Bands: FM Stereo, MW
- Tuner Enhancements: Auto Store
- Station presets: 40

## Connectivity

- Headphones: 3.5 mm
- Other connections: FM Antenna, MW Antenna
- Aux in: Line in

## Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Backlight colour: Blue
- Clock: On main display
- Display Type: LCD

## Accessories

- Included accessories: Screws for wall mounting x 2, AM/FM Antenna, Stand, Guarantee booklet, Quick Use Guide
- Remote control: 23-key with battery
- User Manual: English

## Dimensions

- Packaging dimensions (W x H x D): 328 x 313 x 300 mm
- Set dimensions (W x H x D): 250 x 245 x 96 mm
- Main speaker dimensions (W x H x D): 166 x 245 x 90 mm
- Weight incl. Packaging: 5.3 kg

## Power

- Power supply: 220-240 V, 50 Hz

# Highlights

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2017-04-04

Version: 2.1.9

12 NC: 8670 000 31337  
EAN: 87 12581 34448 1

© 2017 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)