



Philips  
HiFi Stereo Headphone

SHP805



## Hi-Fi

### Large speaker driver

When you're looking for a comfortable HiFi stereo headphone, the SHP 805 is a perfect choice. Its large 40 mm diameter speaker driver delivers impressive sound quality for a personal listening experience that brings your music to life.

#### **The perfect listening experience**

- 40mm speaker driver delivers sound without distortion

#### **You'll forget you're wearing them!**

- Ergonomic cushions improve wearing comfort and bass
- Easy to adjust headband ensures optimum fit and comfort

#### **Always ready**

- The 3 m-long cable is ideal for use with headsets
- Single-sided cable reduces tangling and improves comfort

**PHILIPS**  
sense and simplicity

## Specifications

### Sound

- **Acoustic system:** Open
- **Diaphragm:** Mylar dome
- **Frequency response:** 10–28,000 Hz
- **Magnet type:** Ferrite
- **Maximum power input:** 1500 mW
- **Speaker diameter:** 40
- **Voice coil:** CCAW
- **Sensitivity:** 104
- **Impedance:** 32
- **Type:** Neodymium

### Connectivity

- **Cable Connection:** One-sided
- **Cable length:** 3 m
- **Connector:** 3.5 & 6.3 mm stereo
- **Finishing of connector:** 24k Gold-plated
- **Type of cable:** OFC
- **Detachable cable:** N

### Accessories

- **Adapter plug:** 3.5-6.3 mm

## Product highlights

### 40 mm speaker driver

The 40 mm speaker driver is made of a composite Mylar material for a highly sensitive yet powerful element that delivers sound without audible distortion.

### Ergonomically shaped cushions

The ergonomic ear cushion shape and luxurious materials ensure a more comfortable fit and better bass performance thanks to reduced audio leakage.

### Easy to adjust headband

The easy to adjust mechanism provides a comfortable, close fitting acoustic seal between the ear cushion and ear, ensuring optimal performance.

### 3 m cable

A handy cable length to make it easier for you to move around freely while using your headphones.

### Single-sided cable

The cable is conveniently connected to just one side, considerably reducing the risk of tangling and simplifying winding the cable up for storage.



Issue date 2008-12-19

Version: 1.0.3

12 NC: 9082 100 03925  
EAN: 87 10895 86646 0

© 2008 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)