

Philips  
Micro Hi-Fi System



MCM166

## Enjoy music in great sound

Delight yourself in fantastic sound from the truly compact and stylish Philips Micro Hi-Fi system MCM166. Enjoy your favorite MP3-CD tunes and USB Direct playback richly enhanced by powerful Dynamic Bass Boost.

### Multiple sources for more choices

- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for easy MP3 music playback
- FM digital tuning to preset up to 20 stations

### Enrich your sound experience

- 10W RMS total output power

### Quality sound performance

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound

**PHILIPS**  
sense and simplicity

# Highlights

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be

switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges

for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



# Specifications

## Sound

- Output Power: 2 x 5W RMS
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control 4 modes
- Volume Control: Volume Control up/down

## Loudspeakers

- Main Speaker: 3" woofer

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

## Connectivity

- Headphone: 3.5 mm

- Other connections: FM fixed pigtail antenna
- 3.5mm stereo line in: MP3-Link
- USB: USB host

## Convenience

- Alarms: Sleep timer, CD Alarm, Radio Alarm
- Clock: On main display
- Display Type: LCD
- Backlight color: Blue

## Accessories

- Included accessories: FM/MW Antenna, Guarantee booklet, Quick Use Guide, 3.5mm stereo line in cable
- Remote control: 36-key remote control
- User Manual: English, French, Spanish

## Dimensions

- Set dimensions (W x H x D): 147 x 231 x 209 mm
- Main speaker dimensions (W x H x D): 134 x 233 x 153 mm
- Packaging dimensions (W x H x D): 370 x 270 x 326 mm
- Weight incl. Packaging: 5.1 kg

## Power

- Power supply: 120V, 60Hz



Issue date 2012-07-31

Version: 1.0.2

12 NC: 8670 000 55199  
UPC: 6 09585 17523 5

© 2012 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)