



Philips
Webcam

VGA
CMOS

SPC620NC



Live videochat from Mars!

Have fun with your friends wherever they are. Amaze them by replacing your real-life background with a virtual one. Stun them with the superb image quality. And impress them with clear sound, without distracting background noise.

Superb video chatting experience

- 1.3 Megapixels for higher image quality
- 3 x digital zoom for superb close-ups
- Precision glass lens offers sharper image quality
- Face tracking automatically follows your face

Clear and natural voice

- Built-in digital microphone for quality sound

Fun video features

- Change Your Background
- Exciting fun frames and effects
- Add your own fun logo to personalise your webcast

Perfectly user-friendly

- Compatible with all instant messaging services
- Stable mount on any monitor, laptop or desk
- Snapshot button lets you take great instant photos

PHILIPS

Specifications

Video and snapshot capturing

- Sensor: CMOS
- Sensor resolution: VGA
- Video resolution: VGA
- Snapshot resolution: VGA
- Interpolated snapshot res.: 1.3 MP
- Max. frame rate: 30 fps
- Lens: F2.8, D50°
- White balance: 2600 – 7600 K
- Min. illuminance: < 5 lux
- Colour depth: 24 bit

Mechanics

- Laptop clamp
- LCD clamp
- CRT stand
- Desktop stand
- Built-in digital microphone
- QuickLaunch button
- Snapshot button

Accessories

- Included accessories: User Manual

Software

- VLounge: Premium
- Add video to: Yahoo! Messenger, AOL Messenger, Skype, ICQ, QQ, Windows Live Messenger

System Requirements

- Operating System: Microsoft Windows XP, Microsoft Windows Vista, Microsoft Windows Vista Home
- Processor: Pentium III 800 MHz or faster

- RAM memory: 512 MB RAM
- Sound card
- USB: Free USB port
- Internet connection
- Hard disk space: 200 MB
- CD-ROM or DVD-ROM Drive

Connectivity

- Cable length: 1.5 m
- PC Link: USB 2.0

Dimensions

- Product dimensions (W x H x D): 40 x 82 x 88 mm
- Product weight (g): 110

Packaging Data

- 12NC: 867000028289
- EAN/UPC/GTIN: 87 12581 32419 3
- Quantity: 1
- Height: 186 mm
- Length: 192 mm
- Width: 92 mm
- Gross weight: 0.435 kg
- Tare weight: 0.325 kg

Outer Carton

- EAN/UPC/GTIN: 87 12581 32420 9
- Quantity: 6
- Height: 220 mm
- Length: 392 mm
- Width: 292 mm
- Gross weight: 3.5 kg
- Tare weight: 2.55 kg

Highlights

1.3 Megapixels

With 1.3 Megapixels you can use your webcam as a camera for taking high-quality photographs that are even good enough for printing larger sized high-quality images.

3 x digital zoom

Zoom in and out to get the perfect framing for any image. You control the zoom entirely via the on-screen interface while you are looking at the image so you can adjust it perfectly.

Precision glass lens

Sharp, crisp and clear. Precision glass lens guarantees you high image quality for all applications - from snapshot to video messaging. The finished lenses are coated with a special film to extend their working life and protect them from wear and tear and dust accumulation.

Automatic face tracking

The state-of-the-art camera software automatically detects your face and moves the lens to follow you as you move. You stay in the centre of the image even if you move during a video conference. It gives you the freedom to express yourself and converse naturally.

Built-in digital microphone

The built-in digital microphone allows you to talk naturally and freely or to add sound to a video clip recording.

Change Your Background

Replace your real-life background and fool your friends into thinking you're somewhere else! You can move around and chat as normal, while the software automatically fills in the background behind you. There are 15 great backgrounds to choose from, or you can upload and project your own favourite backdrop.

Exciting fun frames/effects

Keep chatting fun by adding the unexpected. Surprise your friends with one of ten themed fun frames around your face to match your chat. Or entertain them with special fun effects that will make you look like you are a negative, embossed or even distorted.

Add a fun logo to your webcast

Personalise your webcast or blogs by adding your own fun logo. This special software enables you to insert a small image in any corner of the streaming video, in the same way that TV channel logos appear on your television.

Compatible with all services

The webcam and its software have been designed with all instant messaging services in mind. Add video to Skype, Windows Live Messenger, Yahoo! Messenger, AOL Instant Messenger and other services.

Stable mount

The multifunctional stand makes it easy for you to mount the webcam on any monitor, laptop, notebook or flat surface.



Issue date 2017-07-06

Version: 2.1.11

12 NC: 8670 000 28289
EAN: 87 12581 32419 3

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com