



Philips
Bluetooth® mono headset

Earbud
Black

SHB1702



Crystal clear talk with 2 Mic Noise Cancelation

Talk and Music with Voice Alert, Voice command and Supporting multiple devices

Wear it comfortably for hours!

- Ergonomic earhook

Make sure you are clearly understood

- Clear, echo free calls

Talk freely - handsfree and wireless

- Bluetooth enabled wireless handsfree talking
- Wireless call management

Universal: Works with your Bluetooth enabled phone

- Bluetooth HSP/HFP compliant - Universal
- Bluetooth® Stereo (A2DP compliant)

Works with all Bluetooth-enabled devices

- Pair two Bluetooth devices simultaneously

PHILIPS

Specifications

Product dimensions

- Product dimensions (W x H x D):
1.6 x 5.5 x 3.1 cm
- Product dimensions (W x H x D):
0.6 x 2.2 x 1.2 inch
- Weight: 0.032 kg
- Weight: 0.071 lb

Outer Carton

- Outer carton (L x W x H): 65 x 22.5 x 24 cm
- Outer carton (L x W x H): 25.6 x 8.9 x 9.4 inch
- Nett weight: 1.296 kg
- Nett weight: 2.857 lb
- Gross weight: 3.9 kg
- Gross weight: 8.598 lb
- Tare weight: 2.604 kg
- Tare weight: 5.741 lb
- GTIN: 1 48 95185 62217 7
- Number of consumer packagings: 36

Inner Carton

- Inner carton (L x W x H): 23.5 x 21 x 11 cm
- Inner carton (L x W x H): 9.3 x 8.3 x 4.3 inch
- Nett weight: 0.216 kg
- Nett weight: 0.476 lb
- Gross weight: 0.565 kg
- Gross weight: 1.246 lb
- Tare weight: 0.349 kg
- Tare weight: 0.770 lb
- GTIN: 2 48 95185 62217 4
- Number of consumer packagings: 6

Connectivity

- Bluetooth profiles: handsfree, headset
- Bluetooth version: 4.0
- Maximum range: up to 33 feet / 10

Convenience

- Volume control
- Call management: Answer / End call, Call transfer, Chinese voice alert, Last number redial, Microphone mute, Reject call, Switch between call and music, Voice command, Voice dial

Power

- Battery Type: Li-polymer
- Rechargeable
- Power supply headset: via USB adapter
- Standby time: up to 220 hour(s)
- Talk time: up to 6 hour(s)

Accessories

- Included: Earhook (optional), Quick start guide, USB charging cable

Packaging dimensions

- Packaging dimensions (W x H x D):
9.5 x 17.5 x 3.5 cm
- Packaging dimensions (W x H x D):
3.7 x 6.9 x 1.4 inch
- Nett weight: 0.036 kg
- Nett weight: 0.079 lb
- Gross weight: 0.076 kg
- Gross weight: 0.168 lb
- Tare weight: 0.040 kg
- Tare weight: 0.089 lb
- Number of products included: 1
- Packaging type: Blister
- Type of shelf placement: Both
- EAN: 48 95185 62217 0

Highlights

Clear, echo free calls

Enjoy clear, echo free calls with the headsets' highly sensitive microphone and smart acoustic design.

Wireless handsfree talking

Using your cellphone without a headset can be inconvenient and unsafe. In many locations it is also illegal while driving. Wired handsfree kits add the hassle of a cable. A Bluetooth headset replaces the cable with a short range wireless Bluetooth connection, so your hands are free and your freedom to move is not hampered by a cable. Because the transmitted energy close to your head is much lower than that radiated from your mobile phone Bluetooth also decreases potential risks associated with cellphone radiation.

Wireless call management

Manage your call without using your mobile phone. This includes call acceptance, rejection, voice dial and redial. Voice dial and redial have to be supported by your mobile phone.

Bluetooth HSP/HFP compliant

Bluetooth is a cable replacement technology. Bluetooth is a global standard, so Bluetooth devices of different manufacturers can interoperate using shared Bluetooth profiles. HSP (Handset Profile) and HFP (Handsfree Profile) are the profiles required for typical Bluetooth headset operations. If your mobile phone is compliant to HSP or HFP (like virtually any Bluetooth enabled phone) this headset will work with it. The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Koninklijke Philips Electronics N.V. is under license.

Ergonomic earhook

The ergonomic earhooks size can be adapted in various steps to fit your ears, which will not only increase comfort but also ensure a safe fixture. In addition the earhook can be adapted to accommodate both left- and right-ear wearing styles.

Bluetooth® Stereo (A2DP)

This Philips device fully supports Bluetooth Stereo (A2DP). A2DP (Advanced Audio Distribution Profile) compliance enables this headset to receive stereo music from any Bluetooth device that is A2DP compliant. Therefore you can use this headset with any compatible mobile phone, PC, Bluetooth adapter, MP3 player etc. that supports A2DP.

Pair two Bluetooth devices

Pair two Bluetooth devices simultaneously



Issue date 2018-03-09

Version: 1.0.4

12 NC: 8670 001 36681
EAN: 48 95185 62217 0

© 2018 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com