

Philips Ultinon Pro7000
Truck signaling bulb

LED-T10 [≈W5W]

Number of bulbs: 2
24V, 4000 K Warm White
Advanced automotive system

24961WU70X2



Enjoy superior brightness for a safer drive

Superior brightness, safer drive

For unmatched visual comfort and safer driving, choose Philips Ultinon Pro7000 LED signaling bulbs. In exterior or interior applications, their vibrant colors and warm, white light instantly improve driver visibility and wellbeing.

Superior visibility

- Signal your intent with brighter exterior lighting
- Ergonomic design with three-LED array

Performance made to last

- Enhanced lifetime of up to 5,000 hours
- HeatShield ensures durable performance

High-end, stylish signaling

- Upgrade your lights, upgrade your style

Simple plug-and-play replacement

- Easy to install and compatible with most car models
- Electrical compatibility with most vehicles

PHILIPS

Truck signaling bulb
LED-T10 [≈W5W] Number of bulbs: 2, 24V, 4000 K Warm White, Advanced automotive system

LUM24961WU70X2/10

Specifications

Marketing specifications

- Expected benefits: Brighter, elegant signals

Product description

- Base: W2,1 x 9,5d
- Designation: W5W LED White 24961 WU70 24V X2
- Homologation ECE: NO
- Range: Ultinon Pro7000
- Technology: LED
- Type: W5W
- Voltage: 24 V
- Application: Interior lights, front parking/position lights, license plate, 3rd stop light, side indicators
- Designation type: LED-T10 [≈W5W]

Lifetime

- Life time: 5000 hrs

Light characteristics

- Lumens: 110
- Color temperature: 4000 K

Electrical characteristics

- Wattage: 1 W
- Voltage: 24 V

Ordering information

- Order entry: 24961WU70X2
- Ordering code: 02293630

Packaging Data

- EAN1: 8719018022936
- EAN3: 8719018022943
- Packaging type: X2

Packed product information

- Gross weight per piece: 24 g
- Length: 7,0 cm
- Width: 2,5 cm
- Height: 11,5 cm
- Pack Quantity: 2 pcs
- MOQ (for professionals): 10 packs

Outerpack information

- Length: 19,5 cm
- Width: 15,5 cm
- Height: 8,5 cm
- Gross weight per piece: 0,30 kg

Highlights

Powerful brightness

Signaling the intended movement of your vehicle is vital to your safety. To avoid collisions, other people have to know what you're doing. And when poor weather reduces visibility, the need for bright and vibrant signaling becomes even greater. Philips Ultinon Pro7000 LED signaling lights provide you with bright, warm light up to 4000 K for positioning and interior lighting. Your truck says a lot about you, so make a style statement with Philips LED signaling lights.

Uniform light distribution

Whether it's for parking lights, glove compartments or interior lighting, the Philips Ultinon Pro7000 LED gives you uniform light distribution. Its wide angle ensures that the light is projected where you need it.

Elegant LED light

While the main goal of exterior lighting is to help you see and be seen, there's no reason why you shouldn't look good at the same time. If you want to upgrade your style without buying a newer truck, replacing your exterior lighting with Philips Ultinon Pro7000 LED signals is a smart way to spend your money.

Lifetime of up to 5,000 hours

You want bright, stylish truck lights but you don't want to keep replacing failed lamps. That's a major weakness of conventional bulbs - the more powerful the light, the shorter its lifespan. Even at a higher light intensity, LEDs last much longer. Philips Ultinon Pro7000 LED lights are built to last. Due to features such as high-end LED technology and advanced heat-management systems, they last for up to 5,000 hours of operation and are covered by a 3-year warranty*.

Good at handling heat

With HeatShield technology, Philips Ultinon Pro7000 T10 bulbs are resistant to high temperatures even when installed next to headlight bulbs. Made with a special composite material, they can endure any thermal challenge and still offer high performance.

Ready, steady, installed!

Enjoy the plug-and-play experience: the Philips Ultinon Pro7000 comes with standard caps and is polarity-free, so replacement is quick and easy.

Electrical compatibility with most vehicles

LED retrofit and conventional bulbs differ from one another in terms of wattage, composition and power consumption. Replacing your conventional bulbs with other LEDs may prove problematic. Philips Ultinon Pro7000 bulbs are electrically compatible with most trucks. Additional adapters are available as accessories for troubleshooting, if needed. We sell a complete solution.



Issue date 2024-07-01

Version: 2.2.1

EAN: 87 19018 02293 6

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* *2-year standard warranty + 1 year extended. Visit philips.com/auto-warranty to know more about our warranty policy

* Non-ECE compliant