

Philips Sleek micro sound system

dock for iPhone/iPod

### **DCB293**



# Obsessed with sound

# Sound that fits your home

Enjoy DAB radio with the Philips sleek micro music system. Sleek, flat and wall-mountable, it fits any decor. Charge your iPhone/iPod while it plays, or connect your portable player to the USB Direct for all-round music pleasure.

### Enjoy your music from multiple sources

- DAB for clear and crackle-free radio experience
- · Play and charge your iPod/iPhone simultaneously
- Enjoy MP3/WMA music directly from your portable USB drives
- $\bullet$  Play MP3/WMA-CD, CD and CD-RW
- FM digital tuning to preset up to 20 stations
- MP3 Link for portable music playback

## **Enrich your sound experience**

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 20W RMS total output power

### Design that blends into your interior(s)

- Motorized sliding front door adding style and elegance
- Wall-mountable option for flexible placement



# Highlights

### **Digital Sound Control**



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

### **Dynamic Bass Boost**



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Play & charge your iPod/iPhone



Enjoy your favorite MP3 music while charging your iPod/iPhone! The dock lets you connect your portable device directly to the Docking entertainment system so you can listen to your favorite music in superb sound. It also charges your iPod/iPhone while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The Docking entertainment system automatically charges your portable device while it is docked.

### **USB Direct for MP3/WMA music**



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

### **Motorized sliding front door**

A motorized sliding front door adds even more panache to the already sleek design of this system. The stylish yet functional door housing the disc slides up and down vertically in a smooth motion at the touch of a button whenever you feel like changing your music selection. Just sit back and enjoy the dynamic sound performance while watching the disc play through the transparent window.

### **DAB**



DAB (Digital Audio Broadcasting) digital radio is, on top of FM analog transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear and crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can be find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no returning on the move.

### **MP3 Link**



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

### Wall-mountable

The perfect combination of a slim and versatile design, your Philips audio system is cleverly designed to blend into your living space. The base of the audio system is a stand so the system can sit securely and nicely on any shelf or cabinet. When wall mounted you have all the same flexibility of the freestanding stand.

















# Specifications

#### Sound

- Sound enhancement: Dynamic Bass Boost, digital sound control
- Volume control: up/down
- Output power: 2 x 10 W RMS

### Loudspeakers

- No. of built-in speakers: 2
- Speaker drivers: 3" woofer
- Speaker types: bass reflex speaker system

### Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD, USB flash drive
- Disc playback modes: next/previous track search, fast forward/backward, repeat/shuffle/program
- Others: ID3-tag support
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop
- Docking playback modes: fast forward and backward, next and previous track, play and pause

### iPod compatibility

 Compatible with: iPod 5th generation, iPod classic, iPod mini, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod nano 5th generation, iPod touch, iPod touch 2nd generation, iPod touch 2nd gen 8/16/32GB

### iPhone compatibility

• Compatible with: iPhone, iPhone 3G, iPhone 3GS

### Tuner/Reception/Transmission

- DAB: info display, menu, smart scan
- Tuner bands: FM stereo, DAB (Band III)
- Station presets: 20

- Antenna: fixed FM & DAB T-shape antenna
- RDS: program type, RDS clock set, station name
- · Tuner enhancement: auto digital tuning, auto scan

### **Connectivity**

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

#### Convenience

- Alarms: CD alarm, radio alarm, USB alarm, iPod alarm
- Loader type: front, motorised
- · Clock: on main display, sleep timer
- · Charging device: iPhone, iPod
- · Display type: LCD display

### **Accessories**

- Cables/Connection: MP3 Link cable
- · Remote control
- Others: Quick start guide
- · User Manual: English

### **Dimensions**

- Gross weight: 5.5 kg
- Main unit depth: 103.5 mm
- Main unit height: 245 mm
- Packaging width: 620 mm
- Main unit width: 565 mm
- Packaging height: 250 mm
- Packaging depth: 165 mm

#### **Power**

- Power supply: 110 240 V
- Power supply: 50/60 Hz

### Green

• Eco Power standby: 1 W



Issue date 2014-02-12

Version: 2.1.12

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 62096 EAN: 87 12581 53747 0

www.philips.com