



Philips  
Classic DVD micro system

DVD  
CD, MP3-CD, USB, FM  
50W

MCD135

## Obsessed with sound

Relax to great music and movie

Compact yet powerful, this system delivers incredible sound with 50W RMS power. It also plays DVDs, music from USB and FM radio. Its compact design gives you extremely flexible placement, so you can enjoy superb sounds anywhere at home.

### Enrich your movie experience

- Play DVD, DivX®, (S)VCD, MP3-CD, CD(RW) and Picture CD
- Dolby Digital for ultimate movie experience

### Enrich your sound experience

- 2x25W RMS/50W Total Power
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound

### Enjoy your music from multiple sources

- Enjoy MP3/WMA music directly from your portable USB drives
- MP3 Link for portable music playback
- FM digital tuning with presets

# PHILIPS

# Highlights

## Dolby Digital

Because Dolby Digital, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.

## 2x25W RMS/50W Total Power

2x25W RMS/50W Total Power

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be

switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is

also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

## USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.



# Specifications

## Video Playback

- Playback Media: DVD+RW, DVD-Video, Picture CD, Video CD/SVCD, DivX Ultra
- Disc Playback Modes: Angle, Slow Motion, Zoom, A-B Repeat, PBC, Parental control
- DVD Region.: 2
- USB Direct Playback: JPEG

## Audio Playback

- Playback Media: MP3-CD, CD-RW, CD-R, CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Repeat, Shuffle

## Sound

- Output Power: 50W RMS
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control 4 modes
- Sound System: Dolby Digital

## Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 4" woofer

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 10
- Tuner Enhancements: Auto Store

## Connectivity

- Video Output - Analog: Composite CVBS (yellow cinch), S-Video (on Hosiden), Component Y Pb Pr (cinch)
- Other connections: Line out, FM Antenna
- Headphone: 3.5 mm
- Audio Connections: 3.5mm Line in

## Convenience

- Alarms: Sleep timer, CD Alarm, Radio Alarm
- Clock: On main display
- Display Type: White FTD
- OSD Languages: English, Traditional Chinese, Portuguese, Spanish

## Accessories

- Included accessories: Composite video cable (Y), FM/MW Antenna, Guarantee booklet, Quick Use Guide, 3.5mm stereo line in cable
- Remote control: 40-key with Lithium batteries

## Power

- Power supply: 100-240VAC, 50/60Hz

## Dimensions

- Set dimensions (W x H x D): 152 x 170 x 210 mm
- Main speaker dimensions (W x H x D): 152 x 170 x 210 mm
- Packaging dimensions (W x H x D): 535 x 265 x 252 mm
- Weight incl. Packaging: 3.52 kg



Issue date 2014-06-11

Version: 2.2.5

12 NC: 8670 000 66715  
EAN: 87 12581 55883 3

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Music with Digital Right Management not supported.