

Philips
Portable Speaker System



SBA1500



Portable and powerful

Boost your music

Play extra powerful, rich sound to thrill your friends. These speakers come with their own power pack to amplify the music, which also neatly clips together with the speakers for true compact portability. Take them anywhere.

For superb music pleasure

- Boost your music with the integrated amplifier
- Powerful speaker drivers for ultra-realistic sound
- Bass pipe emphasises low tones for a clear, realistic sound
- Wide stereo sound stage when speakers are placed apart.

Share your music anywhere

- Small and lightweight for carrying in your pocket or bag
- Universal use with all portable entertainment equipment

Always ready to go

- Amplifier protects and stores the speakers and cables
- Plug and play with all portable music devices
- Works with or without batteries for extra convenience

PHILIPS
sense and simplicity

Specifications

Sound

- Frequency response: 100–18,000 Hz
- Impedance: 4 ohm
- RMS Power rating: 2 x 1 W
- Speaker diameter: 50 mm

Connectivity

- Cable length: 1.2 m
- Connector: 3.5 mm stereo
- Finishing of connector: Chrome-plated

Convenience

- Operating time: 20 hours
- Power on indication

Accessories

- AC/DC Adapter: No
- Carrying case: Protective Rubber

Power

- Battery type: AAA, R6
- Battery voltage: 1.5 V
- Number of batteries: 3

Packaging dimensions

- Packaging dimensions (W x H x D): 20 x 18 x 10 cm
- Gross weight: 0.569 kg
- Net weight: 0.447 kg
- Tare weight: 0.122 kg
- EAN: 87 10895 92156 5
- Number of products included: 1
- Packaging type: Carton

Outer Carton

- Gross weight: 16.705 kg
- Outer carton (L x W x H): 63.2 x 42.9 x 37.2 cm
- Net weight: 10.728 kg
- Tare weight: 5.977 kg
- EAN: 87 10895 92158 9
- Number of consumer packages: 24

Inner Carton

- Gross weight: 3.883 kg
- Inner carton (L x W x H): 40.6 x 30.5 x 16.8 cm
- Net weight: 2.682 kg
- Tare weight: 1.201 kg
- EAN: 87 10895 92157 2
- Number of consumer packages: 6

Highlights

Boost your music

To get more enjoyment from your music, with extra powerful sound, deeper bass and higher highs. These speakers include a powerful amplifier to create stunning, rich sound.

Powerful speaker drivers

Powerful speaker drivers produce ultra-realistic sound, totally immersing you in the game.

Bass Pipe

Thanks to an acoustically-tuned air channel that turbo-charges the bass notes, you can enjoy fantastic realism and a truly involved listening experience.

Wide stereo sound stage

These portable speakers create a natural stereo sound stage when they are placed apart, giving the impression that each musical instrument occupies a different physical space. The effect is more realistic and more enjoyable.

For portable equipment

Universal use with all portable entertainment equipment. Simply connect using the 3.5 mm plug.

Protective cable management

An all-in-one design that neatly secures and protects both audio cables and speakers, preventing damage and reducing unnecessary wear

Plug and play speakers

The 'plug and play' feature saves you time because you simply connect the speakers to the portable audio player as you would normally connect the headphones, by using the jack plug.

With or without batteries

These portable speakers use either their own batteries or the portable audio player's output signal. This gives you extra convenience — no batteries no longer means no sound.



Issue date 2013-01-10

Version: 4.0.7

12 NC: 9082 100 05704
EAN: 87 10895 92156 5

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com