

Philips  
MP3 Mini Hi-Fi System

**600W**  
subwoofer  
Multisource ripping

**FWM613**



## Obsessed with sound

Play it, rip it and never miss out on favorite radio programs. The Philips Mini hi-fi system will let you rip music files from CDs and radio content. Ultimate powerful bass and virtual surround sound, life's just a big, continuous concert.

### **Multiple source MP3 music**

- Compatible with WMA and MP3 CDs
- Rip music from CDs, radio and karaoke onto USB device
- Play back songs from USB device
- MP3 Link for portable music playback

### **Powerful sound you can hear and feel**

- 600W RMS total output power
- MAX Sound for instant power boost
- Dual amplifier for better sound performance

### **Convenient and easy to use**

- 3-CD changer for WMA/MP3-CD music playback
- Clock, alarm and sleep timer
- Connection for TV or DVD player

### **Be a singing sensation**

- Karaoke for endless singing entertainment at home

# PHILIPS

# Highlights

## MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound

spectrum and volume and a potent audio boost that will add mileage to any music.

## Compatible with WMA and MP3 CD

Compatible with WMA and MP3 CDs

## MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your

favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

## Rip music onto USB device

Rip music from CDs, radio and karaoke onto USB device



# Specifications

## Sound

- Total Sound Power (RMS): 600 W
- Output power: 7800 W PMPO, 4 x 105 W/ch + 180 W RMS
- Sound enhancement: MAX sound, Dynamic Bass Boost 3 steps, incredible surround, digital sound control 4 modes, virtual ambience control

## Loudspeakers

- Number of speaker boxes: 3
- Speaker drivers: 2 x 6.5" woofer, 2" tweeter, 3 way
- Subwoofer types: 8" woofer, passive
- Speaker types: bass reflex speaker system

## Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/one/all/program, repeat/shuffle/program
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, shuffle, stop

## Audio recording

- Recording media: USB device
- USB recording modes: instant record, programmed tracks, schedule radio program, single disc, single track
- USB recording sources: CD, tuner, microphone in, AUX

## Tuner/Reception/Transmission

- Station presets: 40
- Tuner bands: FM, MW
- Antenna: FM antenna, MW antenna
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug & play)

## Connectivity

- Aux in: 2xRCA (Audio)

- USB: USB host
- MP3 Link: 3.5mm stereo line in
- Microphone: dual microphone sockets

## Convenience

- Alarms: CD alarm, USB alarm, radio alarm
- Number of discs: 3
- Clock: on main display, sleep timer
- Loader type: 3 CD carousel
- Display enhancements: DIM mode
- Display type: VFD display
- Karaoke: MIC volume, echo control

## Accessories

- Remote control: 36-key with 2xAAA batteries
- Cables/Connection: \*Flat pin adaptor, MP3 Link cable
- User Manual: B-Portuguese, Spanish
- Others: batteries for remote control, FM/MW antenna, Quick start guide
- Warranty: World Wide Guarantee booklet

## Dimensions

- Gross weight: 28.5 kg
- Main speaker dimensions (W x D): 225 x 275 mm
- Main speaker height: 430 mm
- Main unit depth: 382 mm
- Subwoofer width: 274 mm
- Main unit height: 345 mm
- Subwoofer height: 430 mm
- Main unit width: 265 mm
- Subwoofer depth: 340 mm
- Packaging width: 1250 mm
- Packaging height: 495 mm
- Packaging depth: 340 mm

## Power

- Power supply: 100 - 240V AC, 50/60Hz



Issue date 2014-02-10

Version: 4.0.4

12 NC: 8670 000 50744  
EAN: 87 12581 47182 8

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Avoid extensive use of the set in a volume higher than 85 decibel  
because this may damage your hearing.