



Philips  
Bluetooth party speaker

Bluetooth®



TANX100

## Rock the party

Get the party started right with the Bluetooth speaker that lets you flow on the mic! You get 14 hours play time, plus karaoke functions and lighting effects. Sound is loud and powerful, and you can even plug in a guitar.

### Get the party started right

- 14 hours play time. Loud, powerful sound
- Party light effects. Blaze to the music
- 2x mic inputs and 1x guitar input (6.3 mm)
- Karaoke features: echo, female/male voice switch, vocal fader

### Rock those skills

- 2x2" tweeters. 1x5.25" bass driver
- Up to 10 m wireless range
- Buttons on speaker for volume, music control, lights
- Dials on speaker for mic, echo, and guitar volume

### Bring the beats

- Built-in carry handle. Speaker weighs 5.6 kg
- Dimensions: 268x385x285 mm
- Easy pairing: just press the Bluetooth button
- Line-in and line-out (3.5 mm)

# PHILIPS

# Specifications

## Sound

- Output Power: 80W (maximum)
- Power (RMS and THD %): 40W (THD 1%)
- Sound enhancement: digital sound control, Dynamic Bass Boost, bass reflex system, Karaoke

## Speaker

- No. of sound channels: Mono
- Configuration: bi-Amp
- Tweeter: 2" x 2"
- Woofer: 5.25"
- Color: Black
- Speaker Grille

## Audio Playback

- Playback Media: MP3-USB

## Connectivity

- Line-in: 1x 3.5mm
- Mic in: 2 x (6.3mm w/ vol control)
- Line-out: 1x 3.5mm
- Bluetooth profiles: Streaming Format: SBC, Music streaming (A2DP), Playback/volume control: AVRCP, Multipoint (Multipair) support

## Convenience

- Karaoke: echo control, female/male voice switch, vocal fader
- User Interface: LED: Red for ECO and Standby, Audio tones: BT
- Volume control: Tact switch

## Display

- Speaker light effect

## Accessories

- Included accessories: AC Power Cord, Quick start guide, Warranty certificate

## Power

- AC power supply: Power cord (detachable)
- AC voltage support: 110-220V (full range)
- Power supply: 100-240VAC, 50/60Hz
- Battery Type: Lithium-ion (built-in)
- Battery life time: 14 hr
- Standby mode

## Product dimensions

- Product dimensions (W x H x D): 26.8 x 38.5 x 28.5 cm
- Weight: 5.6 kg

## Packaging dimensions

- Packaging dimensions (W x H x D): 35.8 x 44.7 x 34 cm
- EAN: 48 95229 10439 6
- Gross weight: 7.37 kg
- Nett weight: 5.6 kg
- Number of products included: 1
- Packaging type: Box
- Tare weight: 1.77 kg
- Type of shelf placement: Standing

# Highlights

## Bring the beats

With powerful sound and big, pumping bass, this powerful speaker can fill the room with beats. 14 hours play time from a single charge lets you rock the tunes all night.

## Blaze to the music

Get everyone up and dancing with party light effects. Colored lights on the speakers pulse in time to the music, flash in different orders, or stay on in a steady glow.

## Sing it. Play it.

Mic and guitar inputs (6.3 mm) let you take the party up a notch. Sing to a playlist, or rock out to your own playing. You can even fade out the vocals of a song you're singing along to, so only your voice is heard. Fun karaoke effects give you the ability to add echo to the vocals, or switch vocal sounds from female to male and back again!

## Take the party with you

The built-in carry handle means you can play wherever you like. Take the tunes to a friend's house. Set up on the basketball court. You can even pair with another Philips TANX100 party speaker using the 3.5 mm line-in connection.

## Big sounds, easy pairing

Pairing with your Bluetooth device is simple. Just press the Bluetooth button and the speaker is ready to pair. The wireless range is 10 m.



Issue date 2021-12-13

Version: 3.0.2

12 NC: 8670 001 64427  
EAN: 48 95229 10439 6

© 2021 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)