

Philips
CD Soundmachine
Silver



AZ105S

Program your favorite music

You take pleasure in the simple things in life and delight in convenience. The compact and portable Philips CD soundmachine lets you indulge in the pleasures of enjoying your favorite music with the help of easy-to-use functions.

Enjoy your music from different sources

- Play CD, CD-R and CD-RW
- FM tuner for radio enjoyment
- Audio-in for easy portable music playback

Easy to use

- CD Shuffle/Repeat for personalized music enjoyment
- 20-track CD programmable

Rich and clear sound

• Dynamic Bass Boost for deep and dramatic sound



AZ105S/12

Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW
- Disc playback modes: fast forward/backward, next/ previous track search, repeat/shuffle/program

Tuner/Reception/Transmission

- Tuner bands: FM
- · Antenna: FM antenna

Sound

- Sound enhancement: Dynamic Bass Boost
- Sound system: stereo
- · Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

Loudspeakers

- No. of built-in speakers: 2
- · Speaker grille finishing: metal

Connectivity

· Audio in (3.5mm)





Convenience

· Loader type: top

Power

- Battery type: C size (LR14)
- Battery voltage: 1.5 V
- Number of batteries: 6
- · Power type: AC or battery input

Accessories

- Cables/Connection: power cord
- Others: Quick start guide
- Warranty: Warranty leaflet

Dimensions

- Product dimensions (WxDxH): 262 x 245 x 123 mm
- Packaging dimensions (WxDxH): 284 x 264 x 155 mm
- Product weight: 1.1 kg
- Weight incl. Packaging: 1.8 kg

Highlights

Play CD, CD-R and CD-RW



Philips is known for making products which are compatible with many discs available in the market. This audio system lets you enjoy music from CD,CD-R and CD-RW. CD-RW (CD-Rewritable Compatible) means that your audio system can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players.

CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

20-track CD programmable

The CD progammable playback feature allows you to enjoy your favorite tracks in the sequence you want.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2013-11-20

Version: 1.0.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 94512 EAN: 87 12581 65813 7

www.philips.com

All Rights reserved.

© 2013 Koninklijke Philips N.V.