

Philips
MP3 Mini Hi-Fi System

FWM387



Powerful sound with great connectivity

with USB Direct

For unlimited music enjoyment, the FWM387 offers a 3-CD changer and allows you to enjoy your favourite MP3/WMA music collections directly from your portable USB device. Plus, Max Sound and Dynamic Bass Boost ensure great sound!

Enrich your sound experience

- 240 W RMS total output power
- Play MP3/WMA-CD, CD and CD-RW
- MAX Sound for instant power boost

Continuous enjoyment of your favourite music

- 3-disc changer for WMA-/MP3-CD music playback
- Enjoy MP3/WMA music directly from your portable USB devices
- Auto-stop stereo tape deck
- MP3 Link for portable music playback

Personalised sound settings

- 3-step Dynamic Bass Boost for deep bass experience
- Digital Sound Control for optimised music style settings
- Karaoke for endless singing entertainment at home

PHILIPS
sense and simplicity

Highlights

3-disc changer

With a three-disc changer for music playback, you can choose between three different CDs inside the device at any one time. This convenient feature allows you to savour a variety of music while saving you precious time spent changing CDs frequently.

MAX Sound

MAX Sound technology produces an instant boost in bass and treble, maximising volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass, treble and

volume beyond the original maximum levels without distortion. The end result is a noticeable amplification of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

3-step Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from level one to level three – at the touch of a button! You can customise the bass level that fits your style. Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass

levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



Specifications

Sound

- Total Sound Power (RMS): 240 W
- Output power: 480 W music power
- Sound enhancement: MAX sound, Dynamic Bass Boost 3 steps, digital sound control 4 modes, incredible surround

Loudspeakers

- Number of speaker boxes: 2
- Speaker drivers: 2" tweeter, 5.25" woofer
- Loudspeaker enhancement: 2-way
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/one/all/programme, repeat/shuffle/programme
- Number of decks: 1
- Cassette deck technology: mechanical
- Cassette Playback Modes: semi-auto stop
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, programme play, repeat, shuffle, stop

Audio recording

- Recording media: tape
- Tape recording enhancement: CD synchro start recording

Tuner/Reception/Transmission

- Station presets: 40
- Tuner bands: FM, MW
- Antenna: FM antenna, MW antenna
- RDS: news, programme type, radio text, RDS clock set, station name
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug and play)

Connectivity

- MP3 Link: 3.5 mm stereo line in
- Microphone: microphone socket
- USB: USB host

Convenience

- Alarms: CD alarm, USB alarm, radio alarm
- Number of discs: 3
- Clock: on main display, sleep timer
- Loader type: 3 CD carousel
- Display enhancements: DIM mode
- Display type: VFD display
- Karaoke: MIC volume

Accessories

- Remote control: 23-key with 2 x AA batteries
- Others: batteries for remote control, FM/MW antenna, Quick start guide
- User Manual: multi-lingual
- Warranty: Worldwide Guarantee booklet

Dimensions

- Gross weight: 15 kg
- Main speaker dimensions (W x D): 249 x 250 mm
- Main speaker height: 344 mm
- Main unit depth: 403 mm
- Packaging width: 552 mm
- Main unit height: 310 mm
- Packaging height: 627 mm
- Main unit width: 265 mm
- Packaging depth: 394 mm

Power

- Power supply: 50 Hz
- Power supply: 220 - 240 V

Green

- Eco Power standby: 1 W
- Standby power consumption: < 1 W



Issue date 2011-01-06

Version: 3.0.6

12 NC: 8670 000 49724
EAN: 87 12581 46513 1

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com