



True Wireless Headphones

- Natural sound
- Noise Canceling
- Clearer calls on the go
- Bluetooth LE Audio

TAT3508WT/00

Music to calls, flow through your day

Always be working it! These true wireless noise-canceling earbuds sound great, and they reduce wind noise. You can immerse in your tunes and enjoy clear calls on the go. Slip the charging case into your pocket and you're set for the day.

Benefits

Great sound

- Always hear your music. Noise Canceling
- Clearer calls on the go. They'll hear you, not the noise
- Better connectivity and sound. Next-generation Bluetooth*
- Warm, natural sound. Philips sound signature

Comfortable and convenient

- Multipoint connection and touch controls
- IPX4 splash and sweat resistant
- Philips Headphones app. Control noise canceling and more

- Secure, comfortable in-ear fit

Ready for you

- Always ready. Pocket-sized charging case and mono mode
- No worries. Up to 21 hours play time with the case
- Charging case dimensions: 35x62x28 mm
- Quick charge for 15 minutes and get an extra hour

PHILIPS

Features

Noise Canceling



Noise canceling quietens external noise, including wind, so you can focus on your tunes or calls. Leave it on auto or use the Philips Headphones app to adjust. Want to hear more of what's going on around you? Tap an earbud to activate Awareness Mode.

Clearer calls on the go



When you're on a call, a dedicated mic picks up the sound of your voice while an AI algorithm removes background noise from the world around you. The person you're speaking to will hear you, not the traffic or the chatter of people standing next to you!

Next-generation Bluetooth



These earbuds will work with devices that support Bluetooth LE Audio and the LC3 codec to give you a steadier connection and noticeably better sound. The sound won't dip if you're streaming music or taking calls in built-up areas, and there's virtually no lag if watching movies or gaming.*

Philips sound signature

Music to podcasts, love what you hear! These true wireless earbuds feature large 10 mm drivers, tuned to the Philips sound signature. Whatever you're into, you'll enjoy a warm, natural sound with deep bass.

Pocket-sized charging case

Head out with the small charging case in your pocket and your earbuds will always be ready for you. They'll stay protected and charging when you're not using them, and mono mode means you can use either earbud while the other one charges.

Multipoint and touch controls

Touch controls on the earbud stalks keep things simple and multipoint lets you connect to two Bluetooth devices (iOS or Android) at the same time. Google Fast Pair lets you pair to a compatible Android device with a single tap.

IPX4 splash/sweat resistant

Never mind the weather, an IPX4 rating means these earbuds are splash resistant so they don't mind a little rain! Wearing them during a quick workout or on a particularly hot day? They won't mind a little sweat either.

21 hours play time with case

You get 7 hours play time from a full charge, and an extra 14 hours from the case. Pop the earbuds back in the case and they'll recharge fully in 2 hours. If you need a quick boost, just 15 minutes gives you an extra hour. The case can be charged via USB-C.

Philips Headphones app

You can use the Philips Headphones app to customize noise canceling, turn auto wind noise reduction off, and adjust the level of transparency when using Awareness Mode. An equalizer lets you fine-tune your sounds, and you can keep your headphone's software up to date via the app too.

Secure, comfortable in-ear fit

You get real comfort thanks to soft, interchangeable silicone ear-tip covers. The ear tips insert securely into your ear canal, creating a perfect seal that helps diminish external noise. Plus, the stalks make these earbuds easy to insert and remove.

Specifications

[field not found 'disclaimer_text']

Sound

Impedance	32 Ohm
Speaker diameter	10 mm
Sensitivity	95 dB (1k Hz)
Frequency range	20 - 20,000 Hz
Maximum power input	5 mW
Driver type	Dynamic

ANC features

ANC (Active Noise Canceling)	Yes
ANC technology	Hybrid
Awareness mode	Yes
Auto wind noise cancelation	Yes

Telecommunication

Wind noise reduction	Yes
Microphone for call	an AI mic

Connectivity

Bluetooth version	5.3
Supported codec	SBC LC3
Maximum range	Up to 10 m
Bluetooth profiles	A2DP AVRCP HFP TMAP Bluetooth
Type of wireless transmission	Bluetooth
Multipoint connection	Yes
Wireless	Yes

Convenience

Google fast pair	Yes
Philips Headphones app support	Yes
Firmware updates possible	Yes
Water resistance	IPX4
Mono mode for TWS	Yes
Type of controls	Touch

Design

Color	White
Ear coupling material	Silicone
Ear fitting	In-ear
In-ear fitting type	Silicone ear tip

Power

Music play time	7 + 14 hr
Battery type(Earbud)	Lithium Polymer (built-in)
Battery capacity(Earbud)	55 mAh
Battery type(Charging case)	Lithium Polymer (built-in)
Battery capacity(Case)	400 mAh
Charging time	2 hr
Fast charging time	15 mins for 1 hr
Number of batteries	3 pcs
Battery weight (Total)	11.5 g

Voice assistant

Voice assistant compatible	Apple Siri Google Assistant
Voice assistant activation	Manual
Voice assistant support	Yes

Accessories

Eartips	3 pairs (S/M/L)
Charging case	Yes
Charging cable	USB-C cable, 200 mm
Quick Start Guide	Yes

Dimensions

Charging case dimension(WxDxH)	6.28 x 2.81 x 3.54 cm
Earbud dimension(WxDxH)	2.52 x 2.14 x 2.55 cm

Total weight 0.045 kg

Packaging dimensions

Packaging type	Box
Number of products included	1
Type of shelf placement	Hanging
Height	13 cm
Width	11 cm
Depth	4.2 cm
Gross weight	0.113 kg
Nett weight	0.066 kg
Tare weight	0.047 kg
EAN	48 95229 13161 3

Outer Carton

Number of consumer packagings	24
Length	29.5 cm
Width	25.5 cm
Height	27.7 cm
Gross weight	3.83 kg
Nett weight	1.584 kg
Tare weight	2.246 kg
GTIN	1 48 95229 13161 0

Inner Carton

Number of consumer packagings	3
Length	13.7 cm
Width	11.7 cm
Height	11.9 cm
Gross weight	0.41 kg
Nett weight	0.198 kg
Tare weight	0.212 kg
GTIN	2 48 95229 13161 7

UPC

UPC 8 40063 20311 2

* Requires a software update. The Philips Headphones app will notify you when the latest software version is available.



data subject to change
2023, July 21

Version: 4.0.1
EAN: 4895229131613

© 2023 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com