

Philips
DVD Micro Theater



MCD129

Turn any room into theatre

You're in touch with the latest and the coolest - now get a load of the hot 2-in-1 Micro Hi-Fi with DVD, WMA-CD and MP3-CD playback! Relax to your fave movies and music. Home entertainment will never be the same again!

Enjoy your favorite movies, photos and music

- Play DVD, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience
- Progressive Scan component video for optimized image quality
- Aux-in to enhance TV sound

Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Total 60W RMS / 1200W PMPO

PHILIPS
sense and simplicity

Highlights

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Specifications

Sound

- Output Power: 2x15W + 30W RMS / 1200W PMPO
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital

Loudspeakers

- Main Speaker: 3" woofer
- Subwoofer type: Passive

Video Playback

- Playback Media: DVD+RW, DVD-Video, Picture CD, Video CD/SVCD
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom
- DVD Region.: 3
- Video Enhancement: Progressive Scan

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Top

Connectivity

- Video Output - Analog: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden)
- Aux in: 1x(L/R)/RCA
- Other connections: Digital audio coaxial out, Line out, DIN connection

Convenience

- Display Type: White FTD
- OSD Languages: English, Simplified Chinese

Accessories

- Remote control: 38-key with Lithium batteries
- Cables: Din
- Included accessories: Composite video cable (Y)

Dimensions

- Set dimensions (W x H x D): 218 x 221.5 x 90 mm
- Main speaker dimensions (W x H x D): 125 x 250 x 232 mm
- Packaging dimensions (W x H x D): 550 x 314 x 330 mm
- Subwoofer dimensions (W x H x D): 147 x 250 x 232 mm
- Weight incl. Packaging: 9.1 kg



Issue date 2010-12-08

Version: 2.0.5

12 NC: 9073 100 13416
EAN: 87 10895 97178 2

© 2010 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com