



Philips
docking entertainment
system with Dynamic Bass
Boost

- USB Direct
- FM digital tuner



DC199B

Dock and play your digital music out loud

Free your music and enjoy it in superb sound with friends. Just dock your iPod in the sleek and compact DC199B - it delivers dynamic sound and essential functionalities that let you enjoy music just the way you like it.

Play your iPod content out loud at home

- Play and charge your iPod simultaneously
- Enjoy MP3/WMA music directly from your portable USB drives
- Digital tuning for station presets

Enrich your sound experience

- 2.1 system with a built-in subwoofer
- 4" woofers for improved bass and extended sound spectrum
- Dynamic Bass Boost for deep and dramatic sound

Easy to use

- Wake up and sleep timer functions
- Single remote control for the system and iPod

PHILIPS

Highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

2.1 with built-in subwoofer

2.1 system with a built-in subwoofer

10.2 cm (4") woofers

4" woofers for improved bass and extended sound spectrum

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume

settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Specifications

iPod compatibility

- Compatible with: iPod touch, iPod classic, iPod nano 3rd Generation, iPod 5th Generation, iPod with color display, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation

Connectivity

- USB: USB host
- Aux in: Line-in, 3.5 mm

Tuner/Reception/Transmission

- Tuner Bands: FM
- Auto digital tuning
- Station presets: 20
- Antenna: FM Antenna

Audio Playback

- Cradle playback mode: Charging iPod, Play and Pause, Next and Previous track, Fast forward and backward

Convenience

- Clock/Version: Digital
- Alarms: 24 hour alarm reset, Buzzer Alarm, Radio Alarm, Repeat alarm (snooze), Sleep timer
- Display Type: LCD
- Backlight

- Backlight color: White
- Remote Control: Multi-functional

Sound

- Output power (RMS): 2 x 7.5W + 15W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Volume Control: Volume Control up/down

Loudspeakers

- Built-in speakers: 3
- Loudspeaker types: Integrated subwoofer
- Subwoofer type: Active
- Neodymium magnet system

Power

- Mains power

Dimensions

- Set dimensions (W x H x D):
160 x 171 x 257.7 mm
- Main speaker dimensions (W x H x D):
80 x 90 x 80 mm

Accessories

- Included accessories: Remote Control, AC Power Cord, User Manual, Warranty certificate, World Wide Warranty leaflet



Issue date 2013-05-10

Version: 1.0.4

12 NC: 8670 000 41387
EAN: 87 12581 43529 5

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com