



Philips
Universal remote control

4-in-1 TV/DVD/SAT/AMP

SRU7040



Home entertainment control

Operates more than 1200 brands

If you own a Flat TV and matching home entertainment centre, this stylish ultra-flat remote is the finishing touch! The slim remote provides all the main functions of your home entertainment equipment in one small, fun package.

Single control solution for most devices and brands

- 4-in-1 remote for your TV, STB, DVD and Receiver
- Convenient IR learning from another remote
- Ready for use with Philips equipment

Great convenience

- Ultra-flat design matching flat home entertainment devices
- Dedicated keys for moving around menus
- A light indicates current active device mode
- Low battery indication shows when to refresh batteries

Quick and easy setup

- Automatically searches for your equipment brand
- Batteries are included for unwrap-and-zap
- For questions and assistance call our URC service line
- URC support service via dedicated website

PHILIPS

Specifications

Convenience

- Supported devices: TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP
- TV functions: Programme up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu Control, Colour/Brightness control, Teletext keys, Fast text keys, Previous programme, Sleep/timer, 16:9, Guide, info
- Teletext enhancements: Fast text
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- VCR functions: Transport keys (6), Showview, VCR plus, Menu Control
- SAT/CBL functions: Digit keys, Menu Control, Guide, info, Favourites, Text functions
- Ease of Installation: Autosearch
- Installation steps: 2
- Copy key function
- Language support: GB/F/D/NL/DK/S/N/FIN/I/E/P
- Number of keys: 38
- Pre-programmed for Philips
- Regulatory approvals: CE Mark
- Splash-proof

Power

- Battery lifetime: 12 months
- Number of batteries: 2

Infrared Capabilities

- Operating distance: 7 m
- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 300
- Carrier frequency range: 28–70kHz
- Transmission angle: 90 degree
- Learning IR codes
- Learning frequency range: 30–60 kHz

Accessories

- Battery: Yes, CR2032 Coin cell Battery 3V Lithium

Outer Carton

- Length: 306 mm
- Width: 70 mm
- Height: 160 mm
- EAN/UPC/GTIN: 87 10895 93579 1
- Quantity: 3

Packaging Data

- 12NC: 908210006464
- EAN/UPC/GTIN: 87 10895 93578 4
- Height: 26 mm
- Length: 302 mm
- Width: 155 mm



Highlights

4-in-1 home entertainment remote

Replace a table full of remote controls with one unit that'll operate your TV, satellite receiver (or cable set-top box [STB]) DVD player/recorder and receiver (AMP), regardless of the brand or model.

Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

Ultra-flat

A remote with ultra-flat design is slimmer than a standard remote. This is made possible by replacing the standard batteries by coin cell batteries (the size of a coin) that take up less space.

Dedicated menu keys

Dedicated keys to move easily around your equipment's menus mean simple one finger operation without having to press shift or function shift keys

Device mode indicator

Small lights keep you informed about which device mode is currently active.

Low battery indication

To promptly be aware when the batteries need to be recharged or replaced.

Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.



Issue date 2017-04-04

Version: 2.0.8

12 NC: 9082 100 06464
EAN: 87 10895 93578 4

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com