Rich Video and Audio Experience









Maximize your entertainment experience with the assertive AJL700! With an awesome mix of DVD playback and LCD-TV, you can totally immerse in music and movies – and never leave your kitchen!

Enjoy your favorite movies and music

- Plays DVD, CD and MP3
- LCD TV with integrated tuner for terrestrial reception
- PAL/NTSC compatible

Unexpected power

- Dynamic Bass Boost delivers deeper, more dramatic bass
- · Bass Reflex speakers deliver a powerful, deeper bass
- Motorized CD loader for convenience access

Easy to use

- · Digital tuning with presets
- Cooking timer for your convenience
- · Remote control





DVD Kitchen Radio with LCD-TV

AJL700/37

Technical specifications

Sound

- Loudspeaker types: Bass Reflex Speaker System
- Output power (RMS): 2XIW
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 2"
- Volume Control: Volume Control rotary/ encoder

Video Playback

- Disc Playback Modes: A-B Repeat, Fast Backward, Fast Forward, Introscan, OSD, Pause, Slow Motion, Zoom
- Disc Playback Media: DVD, Video CD, Picture CD, DVD+RW

Audio Playback

- Disc Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20

Audio Recording

- · Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording

Tuner/Reception/Transmission

- Antenna: AM Antenna, FM Antenna
- · Auto digital tuning
- Tuner Bands: FM, MW
- Station presets: 20

Connectivity

AV input: Audio (L/R) x1

- Video input: CVBS Video (RCA) 1x
- DC in: I2V
- Other connections: AM Antenna, FM Antenna, TV in (antenna cable)

Convenience

- Alarms: Buzzer Alarm
- DVD functions: System menu control, Disc menu control, Digit keys, Subtitle select, Audio settings
- · Height Adjustment: 3-step spacer
- Remote Control: Multi-functional

Accessories

 Included Accessories: User Manual, Warranty certificate, AM/FM Antenna, AC-DC Adapter, Batteries for remote control, Remote Control, Quick install guide

Dimensions

- Packaging dimensions (W x H x D): 490 x 414 x 160 mm
- Product dimensions (W x H x D): 409 x 81 x 317 mm
- Weight: 4.2 kg
- Weight incl. Packaging: 5 kg

Power

- · Mains power
- Adaptor type: multi-voltage (AC: 100 240 V, 50 60 Hz)

Picture/Display

- Display screen type: LCD TFT
- Diagonal screen size: 7"
- Aspect ratio: 16:9

Product highlights

Plays DVD/CD/MP3

LCD TV with integrated tuner

This set has a built in tuner to receive terrestrial signals (PAL/SECAM/NTSC) as well as the sound in your local area format.

Digital tuning with presets

Cooking timer

Remote control

PAL/NTSC compatible

Motorized CD loader

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high — at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.



Date of issue 2005-04-04

12 NC: 9073 101 01885

Specifications are subject to change without notice.

Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

© 2005 Koninklijke Philips Electronics N.V.

All Rights reserved.

www.philips.com