



Philips  
Micro Hi-Fi System

CD, MP3-CD, USB, FM

4W  
4W



MCM1006

## Relax with great music

Obsessed with sound

Delight yourself in fantastic sound from the truly compact and stylish Philips Micro Hi-Fi system MCM1006. Enjoy your favorite MP3-CD tunes and USB Direct playback richly enhanced by powerful Dynamic Bass Boost.

### Enjoy your music from multiple sources

- Play MP3-CD, CD and CD-R/RW
- USB Direct for easy MP3 music playback
- MP3 Link for portable music playback
- FM tuner for radio enjoyment

### Enrich your sound experience

- Dynamic Bass Boost for deep and dramatic sound
- Bass Reflex Speakers deliver deep and powerful bass

### Fits any space, any lifestyle

- Compact design

# PHILIPS

# Specifications

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program
- Loader Type: Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

## Sound

- Output Power: 2x2W RMS / 200W PMPO
- Volume Control: Volume Control up/down
- Sound Enhancement: Dynamic Bass Boost

## Loudspeakers

- Main Speaker: 3" woofer



## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo

## Connectivity

- Other connections: FM fixed pigtail antenna
- Audio Connections: 3.5mm Line in
- USB: USB host

## Convenience

- Loader type: top

## Accessories

- Included accessories: IFU / User Manual, World Wide Warranty leaflet

## Dimensions

- Product dimensions (WxDxH): 450 mm x 208.5 mm x 158 mm

# Highlights

## Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Play MP3-CD, CD and CD-R/RW



MP3 stands for "MPEG 1 Audio layer-7.6 cm (3)". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

## USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.



Issue date 2014-06-12

Version: 2.0.2

12 NC: 8670 000 90987  
EAN: 87 12581 64799 5

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)