



Philips  
In-ear headphones with  
mic

8.6-mm drivers/semi-closed back  
In-ear

**SHE8105GD**

## Deep and pure bass – always

with solid metal housing

The Philips SHE8105 in-ear headphones boast high-quality drivers for truly deep bass and sturdy aluminium housing for sound purity. Oval sound tubes ensure ergonomic comfort, while the in-line remote lets you switch easily from music to calls.

### Enjoy quality sound

- Sturdy aluminium housing prevents vibration for sound clarity
- Re-engineered 8.6-mm drivers for responsive deep bass

### Ultimate wearing comfort

- Curved housing and oval sound tubes for ergonomic comfort
- Silicone caps in choice of three sizes for customised fit

### Always ready to go

- Anti-tangle slider keeps your cables together neatly
- Durable Flexi-grip for strong headphone-to-cable connection
- Featuring in-line remote with mic for music and calls

# PHILIPS

In-ear headphones with mic  
8.6-mm drivers/semi-closed back In-ear

SHE8105GD/00

## Highlights

### Aluminium housing



The headphone's housing is crafted from sturdy aluminium, which prevents vibration for the purest sound performance. In addition, it protects the earphones from the wear and tear of everyday use.

### Anti-tangle slider



The smart anti-tangle slider helps you easily keep the two earpiece cables neatly together, simply by gliding it up. No more hassles with tangles or knots!

### Durable Flexi-grip connection

This soft yet durable and flexible connector between the earphone and cable helps protect against potential damage from repeated bending.

### In-line remote with mic



The built-in microphone lets you easily switch from listening to music to taking phone calls - easily, so you'll always stay connected.

### Oval sound tubes

Your in-ear headphones are precisely designed to fit any ear. Their ergonomic oval sound tube and curved architecture ensure an optimised, secure and comfortable fit – always.

### Re-engineered 8.6-mm drivers



Re-engineered 8.6-mm drivers for responsive deep bass

### Silicone caps in three sizes



Your in-ear headphones come with a choice of 3 ear caps – from small to large – so you can select the perfect fit for your ears.

## Specifications

### Sound

- Acoustic system: Semi-closed
- Frequency response: 8–24,000 Hz
- Diaphragm: Mylar dome
- Impedance: 16 Ohm
- Magnet type: Neodymium
- Type: Dynamic
- Voice coil: Copper
- Speaker diameter: 8.6 mm
- Sensitivity: 107 dB
- Maximum power input: 30 mW

### Connectivity

- Connector: 3.5 mm stereo
- Microphone: Built-in microphone
- Type of cable: OFC
- Cable Connection: two-parallel, symmetric
- Finishing of connector: Gold-plated
- Compatible with:: Blackberry, HTC, iPhone, LG, Motorola, Palm, Sony Ericsson, Nokia, Samsung
- Cable length: 1.2 m

### Design

- Colour: Gold



Issue date 2024-03-12

Version: 2.1.7

EAN: 69 25970 70068 9

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)