

Philips
Micro Hi-Fi System

MP3/WMA-CD playback

MCM196



Enjoy MP3-CD music the way you like it

Compact and stylish, this elegant wood-finished beauty packs a powerful punch. Combining superb performance and essential functionalities without compromising on aesthetics, just sit back and enjoy music the way you like it.

Enrich your sound experience

- Play MP3/WMA-CD, CD and CD-RW
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x4W RMS/ 2x350W PMPO

Start the day your way

- Wake-Up and Sleep Timer
- Digital tuning with 40 preset stations for extra convenience

Refined in sound and look

- Elegant wood-finished speakers

PHILIPS
sense and simplicity

Specifications

Sound

- Output Power: 2x4W RMS / 350W PMPO
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 3.5" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 20-Track Programmable
- Loader Type: Top
- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Electronic Speed Control

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: Automatic Recording Level, CD Synchro Start Recording

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

Connectivity

- Other connections: FM fixed pigtail antenna, MW Antenna, Line out
- Aux in: 3.5mm
- Headphone: 3.5 mm

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: LCD

Accessories

- Included Accessories: FM/MW Antenna, Guarantee booklet, Quick Use Guide
- Remote control: 24-key remote with Lithium battery
- User Manual: English, Traditional Chinese
- Quick start guide: English, Traditional Chinese

Dimensions

- Set dimensions (W x H x D): 146 x 228 x 216 mm
- Main speaker dimensions (W x H x D): 146 x 228 x 160 mm
- Packaging dimensions (W x H x D): 380 x 275 x 350 mm
- Weight incl. Packaging: 9.2 kg

Power

- Power supply: 100-240VAC, 50/60Hz



Highlights

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2009-11-06

Version: 1.0.4

12 NC: 8670 000 26948
EAN: 87 12581 32484 1

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com