



Philips
HDMI cable with Ethernet

HDMI 2.0
18 Gbps
1.5 m (4.9 ft)
Audio Return Channel (ARC)

SWV5510



Experience Ultra Hi-Definition images

4K 60Hz Ultra HD with Ethernet

Experience Ultra HD 4K resolution at 60 fps. High speed HDMI supports full 32 channels audio system with up to 1536 KHz sample rate

HDMI Features

- UHD 2160p (4K)
- 3D experience
- Audio Return Channel (ARC)
- 18 Gbps ultra-high-speed data transfer
- 60 Hz frames per second

Enjoy good picture and sound quality

- Gold-plated connectors for better conductivity

PHILIPS

HDMI cable with Ethernet
HDMI 2.0 18 Gbps, 1.5 m (4.9 ft), Audio Return Channel (ARC)

SWV5510/10

Specifications

Packaging dimensions

- Packaging dimensions (W x H x D):
10 x 22 x 3 cm
- Net weight: 0.06 kg
- Gross weight: 0.07 kg
- Tare weight: 0.01 kg
- EAN: 48 95229 11208 7
- Number of products included: 1
- Packaging type: Blister
- Type of shelf placement: Hanging

Outer Carton

- Outer carton (L x W x H): 26.5 x 26 x 22 cm
- Gross weight: 4.66 kg
- Tare weight: 1.78 kg
- Number of consumer packages: 48
- GTIN: 1 48 95229 11208 4
- Net weight: 2.88 kg

Highlights

UHD 2160p (4K)

Supports video resolutions up to 4K or UHD 2160p. This enables your display to rival Digital Cinema systems used in cinemas.

60 Hz frames per second

Superior viewing and gaming experience with maximum 60 frames-per-second images.

Gold-plated connectors

Gold-plated connectors provide better conductivity by lowering contact resistance. They also prevent connector deterioration through oxidation.

3D experience

Supports all 3D video formats, allowing true 3D home theatre and gaming applications.

Audio Return Channel (ARC)

Allows an HDMI-connected TV with built-in tuner to send digital audio data to a surround audio system, eliminating the need for a separate audio cable.



Issue date 2022-07-20

Version: 2.1.3

12 NC: 8670 001 70088
EAN: 48 95229 11208 7

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com