

Philips
Internal Drive

DVD

20 x ReWriter

SPD6005BD



Write and label your DVDs with one unit

Your disc, your project. Why use your handwriting when you can create your own professional label that reflects your memories.

Witness the latest technology

- Drive with lightScribe function
- Double layer writer for +R and -R, DL media
- DVD-RAM format supported

Superior Performance

- 8.5 GB storage capacity on a single-sided double-layer disc
- Amazing 20 x writing speed

Extremely Reliable and Robust

- Dynamic Calibration ensures quality when writing at high speed
- Safe and reliable re-writing with Seamless Link

Convenience

- CD and DVD burner and label printer combined in one device
- Plug and Play for easier installation
- Just flip the disc and label it with 3 steps manual
- Dual Format

PHILIPS
sense and simplicity

Specifications

Writing Speed

- CD-R: 48 X (7200 KB/sec)
- DVD+R: 20 X (27000 KB/sec)
- DVD+R DL: 16 X (21600 KB/sec)
- DVD-R: 20 X (27000 KB/sec)
- DVD-R DL: 12 X (16200 KB/sec)
- DVD-RAM: 12 X (16200 KB/sec)

Re-writing Speed

- CD-RW: 24 X (3600KB/sec) by CAV
- DVD+RW: 8 X (10800KB/sec) by CLV
- DVD-RW: 6 X (8100KB/sec) by CLV

Reading Speed

- Access time: 160 ms
- Buffer size: 2 MB
- CD-R: 48 X (7200KB/sec) by CAV
- DVD-ROM: 16 X (21600KB/sec) by CAV
- DVD-RAM: 5 X (6750KB/sec) by PCAV

Connectivity

- Interface: IDE interface (ATAPI)
- Other connections: 12 V DC in, IDE interface connector, Master/Slave select jumper, Analogue audio Left/Right out, DC power connector, Digital audio out

Convenience

- Ease of Installation: Plug and Play

Accessories

- Included accessories: 4 mounting screws, CD-ROM with software + manual, LightScribe discs, Quick install guide, User Manual

System Requirements

- Hard disk space: 650 MB
- PC OS: Windows® Vista, XP, 2000 SP4, ME, NT, 98 SE
- Processor: Pentium 4 1.3 GHz or Higher CPU
- RAM memory: 128 MB

Technical specifications

- Humidity: 15 - 80 %RH (no condensation)
- Operating temperature range: 5 - 50 °C
- Safety standards: EN60950, EN60825, UL1950
- EMC standards: EN55022, EMS55024, FCC Part 15
- Storage temperature range: -40 - 65 °C

Outer Carton

- Gross weight: 9.72 kg
- Outer carton (L x W x H): 48 x 47 x 22 cm
- Net weight: 8.82 kg
- Tare weight: 0.9 kg

Packaging dimensions

- Packaging dimensions (W x H x D): 22.8 x 20.5 x 9.1 cm
- Gross weight: 1.097 kg
- Net weight: 0.882 kg
- Tare weight: 0.215 kg

Highlights

LightScribe

LightScribe Direct Disc Labelling makes messy marker pens and awkward stick-on labels a thing of the past! Simply flip over your specially coated recordable/re-writable CD or DVD, re-insert it in the drive and 'burn' fantastic labels with the look and quality of professional silk-screened labels. You can mix text and personalised graphics using the software provided and even add to the label at a later date. It makes finding your archived movies, music, photos and data files easier than ever before.

Dynamic Calibration

Dynamic Calibration optimises DVD writing quality of high-speed DVD+RW drives.

Dual format writer on +/- DL

New drive, enabling writing on both +R and -R 8.5 GB double layer media

Burner and Printer in one

LightScribe technology adds label printing functions to your CD and DVD burner.

Plug and Play

Plug and Play gives you the ability to install or add a new component and have it work without having to perform any complex installation procedures or technical analyses.

Seamless Link

Seamless Link prevents loss of discs caused by writing errors

8.5 GB of storage capacity

Store 8.5 GB of data or 4 hours of DVD quality video on one single-sided double-layer disc

DVD-RAM

The DVD-RAM format is supported, which makes this product a true MultiRecording drive supporting all CD and DVD formats.

20 x writing speed

With the latest technology this drive has a maximum 20 x writing speed. This creates the fastest drive in the world with speed and stability.



Issue date 2011-09-23

Version: 2.0.3

12 NC: 8670 000 36223
EAN: 87 12581 38848 5

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com