

Philips  
DVD Micro Theatre

MCD122



# Enjoy great movie experience

with USB direct playback

Be assured of cinematic room-filling sound with the Philips DVD micro theatre MCD122. The system backed with 40 W RMS total output power allows you to feel every sound effect. Also features USB Direct for photo and music playback.

## Enrich your movie experience

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) and Picture CD
- Dolby Digital for ultimate movie experience
- Progressive Scan component video for optimised image quality

## Enrich your sound experience

- USB Direct for music and photo playback
- 2 x 20 W RMS/40 W Total Power
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound

## Start the day your way

- Digital tuning with 20 pre-set stations for extra convenience
- Wake-up and sleep timer functions

# PHILIPS

# Highlights

## USB Direct

Simply plug your USB device into the system and share your stored digital music and photos with your family and friends.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen

music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be

switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Dolby Digital

Because Dolby Digital standards, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.



# Specifications

## Sound

- Output Power: 2 x 20 W RMS
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital
- Output power (RMS): 40 W

## Loudspeakers

- Main Speaker: 4" woofer, Bass Reflex Speaker System

## Video Playback

- Playback Media: DivX, DVD-Video, Picture CD, Video CD/SVCD, DVD+R/+RW, DVD-R/-RW, DVD, DVD+RW
- Disc Playback Modes: A-B Repeat, Angle, Zoom, Slow Motion, Parental control, PBC, Disc Menu, Fast Reverse, Fast Forward, OSD, Resume Playback from Stop
- DVD Region.: 2
- Video Enhancement: Progressive Scan

## Still Picture Playback

- Picture Compression Format: JPEG
- Playback Media: DVD+R/+RW, Picture CD, CD-R/RW

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD, USB flash drive
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Shuffle Play, Fast Forward/Reverse, Next/Previous Track Search
- Loader Type: Tray
- ID3-tag support
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop
- Number of Discs: 1

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo

- Auto digital tuning
- Station presets: 20
- RDS: RDS Clock Set, Station Name, Programme Type

## Connectivity

- Other connections: FM Antenna, Digital audio coaxial out
- Video Output - Analogue: Composite CVBS (yellow cinch), Component Y Pb Pr (cinch), SCART
- Headphones: 3.5 mm
- Audio Connections: Analogue Audio Out (L/R), RCA Aux in
- USB: USB host
- 3.5 mm stereo line in: MP3-Link

## Convenience

- Alarms: Sleep timer, CD Alarm, Radio Alarm, USB alarm
- Clock: On main display
- Display Type: LCD
- Eco Power Standby: 1 watt

## Accessories

- Included accessories: Composite video cable (Y), World Wide Warranty leaflet, AC Power Cord, FM antenna, IFU/User Manual, Quick Use Guide
- Remote control: 38-key with Lithium batteries

## Dimensions

- Set dimensions (W x H x D): 220 x 90 x 240 mm
- Main speaker dimensions (W x H x D): 140 x 220 x 160 mm
- Packaging dimensions (W x H x D): 395 x 310 x 280 mm
- Weight incl. Packaging: 6 kg

## Power

- Power supply: 220-240 V, 50 Hz



Issue date 2013-05-10

Version: 1.0.9

12 NC: 8670 000 55209  
EAN: 87 12581 49593 0

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)