

Philips MP3 portable speaker

• Universal 3.5 mm



SBA3000



Great sound on the go Un son exceptionn où que vous alliez



# Exceptional bass

for music enjoyment on the go

Move with your music! Enjoy stereo sound wherever you go on a travel speaker with rich bass performance. Secure the line-in cable and use as a lanyard for easy portability. Inside, a digital amplifier eliminates mobile-phone interference.

# Enjoy your music in stereo

- Lightweight, portable design for music enjoyment any time
- · Mobile phone shielding technology for static-free sound
- Universal: works via your device's 3.5 mm headphone jack

# Take your music with you

- 30 hours of continuous play for worry-free enjoyment
- · Battery powered for portability
- Carrying pouch to protect your speakers when not in use
- · Line-in cable becomes a lanyard for easy portability

# **Powerful Sound**

- Dynamic bass boost hear the deepest, richest bass
- Class 'D' digital amplifier for quality sound performance
- Incredible Surround<sup>™</sup> for enhanced audio enjoyment



# **Highlights**

# **Dynamic bass boost**



Innovative technology delivers unbelievably deep, rich bass from compact speakers. Dynamic bass boost emphasises the bass content of the music throughout the range of volume settings from low to high - at the touch of a button!

# 30 hours of continuous play

Powered by batteries, this speaker offers up to 30 hours of continuous play for worry-free enjoyment when you're listening to your music on the go.

### **Battery powered**

Powered by batteries, it's easy to take with you for enjoyment on the go - anywhere and everywhere.

# **Carrying pouch**



Look after your speaker and stop the cable getting tangled by storing it in this handy soft pouch when

Class 'D' Amplifier
The Class 'D' Digital Amplifier takes an analogue signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, the Class 'D' Digital Amplifier has over 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

# **Incredible Surround™**

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

# Lightweight, portable design



The durable, lightweight material and design mean you can carry the speakers with you wherever you

# Line-in doubles as lanyard

These speakers are ready to go! When it's time to take your music on the go, reconnect the line-in cable and secure it in place to use as a convenient

# Mobile phone shielding

Mobile phone shielding technology is an advanced circuitry design that cuts out mobile phone interference to ensure static free sound

# Universal 3.5 mm headphone jack

Plug and play with any of your mobile devices that have a 3.5 mm headphone jack - iPods, iPhones, GoGears, MP3 players, laptops, netbooks, music phones and more.

# Specifications

# Design and finishing

· Colour(s): Black

# **Accessories**

- Carrying case: carrying case included
- · Batteries: not included

- Frequency response: 150 16,000 Hz
- Impedance: 4
- RMS Power rating: 4 W
- · Speaker diameter: 40 mm
- Type: Neodymium
- · Sound Enhancement: Class "D" Digital Amplifier, Dynamic Bass Boost, Incredible Surround

# **Power**

- · Battery type: AA
- · Operating time on battery: 30 hr
- Number of batteries: 4

#### Convenience

· Volume control: volume control feature

# **Packaging dimensions**


- Packaging type: Carton
- Number of products included: 1
- Packaging dimensions (W x H x D): 9.42 x 22.5 x 9.42 cm
- Gross weight: 0.4 kg
- Net weight: 0.229 kg
- · Tare weight: 0.171 kg
- EAN: 87 12581 50193 8

# **Outer Carton**

- Number of consumer packages: 6
- Outer carton (L x W x H): 31.9 x 24.9 x 21.7 cm
- Gross weight: 3.053 kg
- Net weight: 1.374 kg
- Tare weight: 1.679 kgEAN: 87 12581 50204 1

# **Inner Carton**

- Number of consumer packages: 2
- Inner carton (L x W x H):  $19.7 \times 10.2 \times 23.6$  cm
- Gross weight: 0.909 kg
- Net weight: 0.458 kg
- · Tare weight: 0.451 kg





Issue date 2013-05-10

Version: 3.1.7

12 NC: 8670 000 55842 EAN: 87 12581 50193 8 © 2013 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com