

Philips Ultinon Pro7000  
Truck signaling bulb

LED-WHITE [≈R5W/R10W]

Number of bulbs: 2  
12/24V, 6000 K Cool White  
Advanced automotive system

24805CU70X2



## Enjoy superior brightness for a safer drive

### Superior brightness, safer drive

For unmatched visual comfort and safer driving, choose Philips Ultinon Pro7000 LED signaling bulbs. In exterior or interior applications, their vibrant colors and crisp, white light instantly improve driver visibility and wellbeing.

#### **Superior visibility**

- Signal your intent with brighter exterior lighting
- Ergonomic design with three-LED array

#### **High-end, stylish signaling**

- Upgrade your lights, upgrade your style

#### **Performance made to last**

- Enhanced lifetime of up to 5,000 hours

#### **Simple plug-and-play replacement**

- Easy to install and compatible with most truck models

# PHILIPS

# Specifications

## Marketing specifications

- Expected benefits: Brighter, elegant signals

## Product description

- Base: BA15s
- Designation: R5W/R10W LED White 24805 CU70 24V X2
- Homologation ECE: NO
- Range: Ultinon Pro7000
- Technology: LED
- Type: R5W/R10W
- Voltage: 12V + 24V V
- Application: Front and rear position lights, side repetitor, interior and license plate for 12 and 24 V vehicles
- Designation type: LED-WHITE [≈R5W/R10W]

## Lifetime

- Life time: 5000 hrs

## Light characteristics

- Lumens: 130
- Color temperature: 6000 K

## Electrical characteristics

- Wattage: 1.05 W (12V) 1.25 W (24V) W
- Voltage: 12/24 V

## Ordering information

- Order entry: 24805CU70X2
- Ordering code: 02315530

## Packaging Data

- EAN1: 8719018023155
- EAN3: 8719018023162
- Packaging type: X2

## Packed product information

- Gross weight per piece: 24 g
- Length: 7,0 cm
- Width: 2,5 cm
- Height: 11,5 cm
- Pack Quantity: 2 pcs
- MOQ (for professionals): 10 packs

## Outerpack information

- Length: 19,5 cm
- Width: 15,5 cm
- Height: 8,5 cm
- Gross weight per piece: 0,30 kg

# Highlights

## Powerful brightness

Signaling the intended movement of your vehicle is vital to your safety. To avoid collisions, other people have to know what you're doing. And when poor weather reduces visibility, the need for bright and vibrant signaling becomes even greater. Philips Ultinon Pro7000 LED signaling lights provide you with a bright, daylight effect plus up to 6000 K for positioning and interior lighting. Your truck says a lot about you, so make a style statement with Philips LED signaling lights.

## Uniform light distribution

Whether it's for parking lights, license-plate lights or interior lighting, the Philips Ultinon Pro7000 LED gives you uniform light distribution. Its wide angle ensures that the light is projected where you need it.

## Elegant LED light

While the main goal of exterior lighting is to help you see and be seen, there's no reason why you shouldn't look good at the same time. If you want to upgrade your style without buying a newer truck, replacing your exterior lighting with Philips Ultinon Pro7000 LED signals is a smart way to spend your money.

## Lifetime of up to 5,000 hours

You want bright, stylish truck lights but you don't want to keep replacing failed lamps. That's a major weakness of conventional bulbs - the more powerful the light, the shorter its lifespan. Even at a higher light intensity, LEDs last much longer. Philips Ultinon Pro7000 LED lights are built to last. Due to features such as high-end LED technology and advanced heat-management systems, they last for up to 5,000 hours of operation and are covered by a 3-year warranty\*.

## Ready, steady, installed!

Enjoy the plug-and-play experience: the Philips Ultinon Pro7000 comes with standard caps and is polarity-free, so replacement is quick and easy.



Issue date 2024-07-01

Version: 2.2.1

EAN: 87 19018 02315 5

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* \*2-year standard warranty + 1 year extended. Visit [philips.com/auto-warranty](http://philips.com/auto-warranty) to know more about our warranty policy  
\* Non-ECE compliant