



Philips Streamium  
Wireless Music Station

**Streamium**

WAS7000

## Enjoy all your music in every room

### Total music enjoyment and freedom

With the Philips WAS7000 in any room, you can instantly play your whole life's music streamed wirelessly from the Music Center. Plus, you can also playback your GoGear or iPod by using the optional 2-in-1 dock.

#### Unlimited listening pleasure - wirelessly

- Wireless streaming between Music Center and Station(s)
- USB Direct for MP3/WMA music playback
- Alarm and timer functionality
- Docking cradle for GoGear and iPod (optional)
- Wireless streaming from PC via UPnP

#### Easy navigation and control

- Music Follows Me: take your music with you from room to room
- Music Broadcast for simultaneous playback to all Stations

#### Quality sound performance

- Super Sound Panel for clear and deep bass sound
- Class 'D' digital amplifier for quality sound performance

**PHILIPS**

# Specifications

## Sound

- Equalizer settings: Classic, Jazz, Pop, Rock, Techno, Neutral
- Sound Enhancement: Dynamic Bass Boost 3 steps, Equalizer, Incredible Surround, Treble and Bass Control, Smart equalizer
- Music Power: (20) W
- Type: Super Sound Panel Speakers
- Volume Control: Volume Control up/down
- Output Power: 10W + 10W Music Power

## Loudspeakers

- Built-in speakers: 2
- Loudspeaker types: Super Sound Panel, Integrated subwoofer, Non-detachable

## Audio Playback

- Compression format: MP3, WMA, PCM
- ID3-tag support
- Hard Disk Playback Mode: Album, Genre, Playlist, All tracks, Same Artist, Same Genre, Uncompressed tracks
- Hard Disk Streaming Mode: Wi-Fi streaming to 5 stations, "My Room, My Music", "Music Follows Me", "Music Broadcast"
- Sample frequencies: 8-48 kHz (MP3)

## Tuner/Reception/Transmission

- Tuner Bands: FM
- Auto digital tuning
- Auto store
- Number of Preset Channels: 50

## Connectivity

- Audio cinch in: Analog AUX (Center/Station)
- Headphone: 3.5 mm
- Antenna: FM Dipole

- Aux in: Line in
- Wireless connections: Wireless LAN(802.11g)
- Power: 220 V 50 Hz
- Wireless Universal Plug & Play: Enabled
- LAN wired: Ethernet (RJ 45) 1x

## Convenience

- Display Type: LCD, 128 x 96 dot matrix, 48 mm x 42 mm (Station)
- Backlight
- Backlight color: White
- On-Screen Display languages: English, Dutch, French, German, Italian, Spanish
- Digital Content Management: WADM software included
- Eco Power Standby: 1 watt
- Headphone jack
- Remote control: 1-Way
- Signal strength indication
- Wall mountable / Ceiling Throw: Wall Mountable

## Accessories

- Cables: Ethernet Cable
- CD-ROM: Installation CD-ROM and WADM software
- Remote control: 1-way Remote
- Batteries: 2 x AA
- Warranty Card: Warranty Card

## Dimensions

- Master carton weight: 5.1 kg
- Product dimensions (WxDxH): 360mm x 128mm x 283mm
- Set weight: 4.2 kg
- Carton dimensions (WxDxH): 422mm x 201mm x 349mm

# Highlights

## Wireless streaming

With wireless streaming, you don't need to download and store large music files on our audio device. Instead, you can listen to favorite songs as they are continuously streamed to all the Music Stations - at the same time. Have your music follow you from room to room with Music Follows Me - no need to restart navigation and playback. Music Broadcast simultaneously broadcasts your desired music from the Center to all Stations. And with My Room, My Music, any family member can enjoy selected music from the stored collection in any room that is equipped with a Wireless Music Center or Station.

## USB Direct

With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

## Universal Plug & Play

Universal Plug & Play is an industry standard technology that lets you connect to any Universal Plug & Play enabled device to receive or transmit music. Your Wireless Music Center utilizes Universal Plug & Play to ensure an easy and standard way to connect to other Universal Plug & Play enabled devices. You can easily connect your Wireless Music Center to other media devices to receive or to transfer content.

## Super Sound Panel

Super Sound Panel is an innovative, flat speaker panel that uses cutting-edge technology to provide high quality, full-range audio from a flat and compact speaker unit.



My room my music



Music follows me



Music broadcast



Issue date 2014-02-07

Version: 5.2.13

12 NC: 9073 100 13233  
EAN: 87 10895 96653 5

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)