

Philips
MP3 Mini Hi-Fi System

FWM143



Listen to your favourite MP3-CD music in rich sound

Get the most out of your music with the Philips FWM143 Mini Hi-Fi System, featuring 2-way Bass Reflex Speaker System for rich sound. Optimise your sound settings by adjusting the balance for different music genres with Digital Sound Control.

Enrich your sound experience

- 2 x 20 W RMS total output power
- 2-Way Bass Reflex Speaker System for powerful sound

Continuous enjoyment of your favourite music

- 10 hours of MP3-CD music
- AM/FM tuner
- Stereo cassette deck

Personalised sound settings

- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimised music style settings

PHILIPS

Specifications

Sound

- Total Sound Power (RMS): 40 W
- Output Power: 800 W PMPO
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control

Loudspeakers

- Main Speaker: 4" woofer, Piezo tweeter, 2-way, Bass Reflex Speaker System
- Number of Loudspeakers: 2

Audio Playback

- Loader Type: Tray
- Number of Discs: 1
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Next/Previous Track Search, Fast Forward/Reverse, 20-Track Programmable, Repeat Play, Shuffle Play
- Cassette Deck Technology: Mechanical
- Number of decks: 1

Audio Recording

- Recording Media: Tape

Tuner/reception/transmission

- Tuner Bands: FM, FM Stereo, MW

Connectivity

- Audio Connections: RCA Aux in

- Headphones: 3.5 mm
- Other connections: AM Antenna

Convenience

- Clock: On main display
- Display Type: LCD
- Alarms: CD Alarm, Radio Alarm, Sleep timer

Accessories

- User manual: 16 languages
- Included Accessories: AM antenna, Remote Control, Flat pin adapter, FM/MW Antenna
- Guarantee booklet: Global version
- Quick start guide
- Remote control: 20-key
- Standard Package Includes: International Guarantee

Dimensions

- Set dimensions (W x H x D): 220 x 292 x 285 mm
- Main speaker dimensions (W x H x D): 190 x 292 x 183 mm
- Packaging dimensions (W x H x D): 510 x 350 x 416 mm
- Weight incl. Packaging: 9.5 kg

Power

- Power supply: 200-240 V
- Standby power consumption: 1 W

Highlights

2-Way Bass Reflex System

2-Way Bass Reflex Speaker System for powerful sound

10 hours of MP3-CD music

MP3 stands for "MPEG 1 Audio layer-3". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the Internet, allowing quick and easy audio file transfer.

AM/FM tuner

AM/FM tuner

Stereo cassette deck

Stereo cassette deck

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of preset Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



Issue date 2013-05-10

Version: 1.1.2

12 NC: 8670 000 47356
EAN: 87 12581 45033 5

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com