



Philips
Car entertainment system



CSP550

Your mobile music theater

with superb sound performance

Play your music loud without distortion with the 13cm Philips Car component speaker system CSP550. With peak music power at 210W and an external crossover network to restore high fidelity details, music is presented with clean sound.

Hear every sound detail

- External crossover network precisely restores original sound
- Fiber-composite cone delivers sound with lowest distortion
- Soft silk dome tweeter to restore high fidelity details
- Swivel tweeter to optimize high-frequency response

Extra music power on the road

- 40W RMS power handling
- Butyl rubber surround for maximum smooth response
- Strong ferrite magnet for high power performance

High durability, sustainable performance

- Sturdy fiber-composite cone for all-weather performance
- Stylish speaker grille protects against damages
- Endurance and performance stability in extreme conditions

PHILIPS
sense and simplicity

Specifications

Sound

- Output power (RMS): 40W
- Peak Music Power: 210W
- Sensitivity: 90dB
- Frequency response: 40-35k Hz
- Impedance: 4 Ohms

Loudspeakers

- Speaker type: Component speaker
- Number of ways: 2-way
- Speaker size: 13cm (5.25")
- Number of Loudspeakers: 4

Woofers

- Diaphragm: Cone
- Diaphragm material: Fiber-composite
- Surround: Rubber
- Voice coil: Single
- Voice coil material: Copper
- Magnet: Ferrite
- Magnet mass: 11 Oz
- Damper: Conex

Tweeter

- Size: 36mm (1-2/5")
- Diaphragm: Dome
- Diaphragm material: Silk
- Magnet: Neodymium
- Mounting options: Angle mounting, Flush mounting, Surface mounting, Swivel mounting

Accessories

- Crossover network: Passive
- Speaker grille: With metal net
- Quick start guide: English, Simplified Chinese
- Angle adapter: 2
- Fix frame: 2
- Mounting bracket: 2
- Cables: Speaker wires

Dimensions

- Product dimensions (W x H x D):
159 x 69 x 159 mm
- Mounting depth: 52 mm



Issue date 2011-10-18

Version: 1.0.2

12 NC: 8670 000 56225
EAN: 87 12581 50422 9

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com