



Philips
Micro music system

• Bluetooth



BTM2056

Sound that fits your home

Obsessed with sound

Let your portable music play on at home. This Philips micro music system comes with USB Direct and MP3-link. Even with wireless music streaming via Bluetooth, this sound system gives you fuss-free musical enjoyment.

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 15 W maximum output power

Enjoy your music from multiple sources

- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for MP3/WMA music playback
- MP3 Link for portable music playback
- Digital tuning with preset stations for extra convenience
- Radio Data System for station information and data services
- Wireless music streaming via Bluetooth

Design that blends into your interior

- Wall-mountable option for flexible placement
- Motorised sliding front door adding style and elegance

PHILIPS

Highlights

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your

favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

Radio Data System (RDS)

The Radio Data System (RDS) lets you tune into radio stations without having to remember the frequencies. In standard mode, RDS displays the station name instead of the transmission frequency, facilitating quick and easy tuning. RDS also allows stations to send text messages such as news and station information directly to the radio display. Commonly used in Europe, RDS text is sent out on the same frequency the radio station broadcasts on. You can choose either the basic RDS display (station name) or subscribe to additional text-based services.

Wall-mountable



The perfect combination of a slim and versatile design, your Philips audio system is cleverly designed to blend into your living space. The base of the audio system is a stand so the system can sit securely and nicely on any shelf or cabinet. When wall mounted you have all the same flexibility of the freestanding stand.

Wireless music streaming

Your speaker supports Bluetooth music streaming. It lets you enjoy your favourite tunes in high-quality music wirelessly from your Bluetooth-enabled devices.



Specifications

Sound

- Sound enhancement: digital sound control, Dynamic Bass Boost
- Volume control: up/down
- Total Sound Power (RMS): 15 W

Loudspeakers

- No. of built-in speakers: 2
- Speaker drivers: 2.75" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive, WMA-CD
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, repeat, shuffle, stop

Tuner/Reception/Transmission

- Tuner bands: FM mono, FM stereo
- Station presets: 20
- RDS: programme type, radio text, RDS clock set, station name
- Antenna: FM antenna (75 ohm)
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug and play)

Connectivity

- Headphones: 3.5 mm
- MP3 Link: 3.5 mm stereo line in
- USB: USB host
- Bluetooth profiles: A2DP

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display, sleep timer
- Display type: LCD display
- Loader type: front, motorised

Accessories

- Included accessories: AC-DC Adapter, FM antenna, Quick Use Guide, Screws for wall mounting x 2
- Remote control: 31-key remote
- User Manual: 16 languages

Dimensions

- Set dimensions (W x D): 400 x 98 mm
- Set height (with stand): 235 mm
- Packaging width: 456 mm
- Packaging height: 251 mm
- Packaging depth: 197 mm
- Gross weight: 4.2 kg
- Net weight: 3.3 kg

Power

- Power supply: 110-240V, 50/60 Hz



Issue date 2013-05-29

Version: 1.0.7

12 NC: 8670 001 00091
EAN: 08 71258 16770 15

© 2013 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com