



Philips
Universal remote control

3in1 for TV/DVD/STB

SRU5130



Full function replacement

Operates more than 1000 brands

This universal remote control is the perfect choice if you want maximum functionality for 3 device out of a choice of 6, with optimal convenience. The natural fit shape ensures comfortable control!

Ideal replacement for your old remote

- Control up to 3 devices out of a choice of 6
- Ready for use with Philips equipment

Great convenience

- Ergonomic shape enables comfortable control
- Easy to use grouped functions
- Batteries are included for unwrap-and-zap

Quick and easy set-up

- Easy setup with fast key recognition
- For questions and assistance call our URC service line
- URC support service via dedicated website

PHILIPS

Specifications

Convenience

- Supported devices: TV, DVD, VCR, CABLE, SAT, DVB-T
- TV functions: Program up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu control, Color/Brightness control, Teletext keys, Fast text keys, Previous program, Sleep/timer, 16:9, Guide, info
- Teletext enhancements: Fast text
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- VCR functions: Transport keys (6), Showview, VCR plus, Menu control
- Installation steps: 2
- Copy key function
- Language support: GB/BL/CR/CS/GR/HU/PL/RO/RU/SK/SV/UK
- Number of keys: 42
- Preprogrammed for Philips
- Regulatory approvals: CE Mark
- Splash proof
- SAT/CBL functions: Channel up/down, Digit keys, Favourites, Guide, info, Menu control, Text functions, Volume up/down, mute

Accessories

- Battery: Yes, 1.5V Battery R03/AAA

Infrared Capabilities

- Operating distance: 33 ft (10 m)

- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 1000
- Carrier frequency range: 24 - 55 kHz
- Transmission angle: 90 degree

Power

- Battery lifetime: 12 Months
- Number of batteries: 2
- Battery type: AAA

Outer Carton

- GTIN: 1 87 12581 44081 4
- Number of consumer packagings: 6
- Gross weight: 1.705 kg
- Outer carton (L x W x H): 30.9 x 14.9 x 16.1 cm
- Nett weight: 0.696 kg
- Tare weight: 1.009 kg

Packaging dimensions

- EAN: 87 12581 44081 7
- Number of products included: 1
- Packaging type: Blister
- Type of shelf placement: Laying
- Packaging dimensions (W x H x D): 15.7 x 30.4 x 2.4 cm
- Gross weight: 0.245 kg
- Nett weight: 0.116 kg
- Tare weight: 0.129 kg

Highlights

3 out of 6 remote

The controller provides the convenience of controlling 3 out of a choice of 6 home entertainment devices with one remote control. The remote can be easily programmed to control almost any brand of almost all audio/video equipment, using the on-board IR code database. One single remote to operate all your devices, without the hassle of searching for the right remote!

Ergonomic design

The smooth rounded shape fits perfectly in your hand for natural, balanced operation. It looks great too!

Fast key recognition

Fast key recognition helps to quickly and easily correct keys that are not working after installing the brand of your equipment on your remote. Just press the key for 5 sec while pointing the remote at your device, and once the device reacts you have fixed the key.

Easy to use grouped functions

Easily grouped functions allows you to easily recognize the buttons you need to control a specific audio video device. All functions of the device are grouped together on the remote. Moreover the top part of the remote is made up of different colour parts (black, silver, aluminum, ...) as well as different key finishings (black, silver, mat, glossy, ...) to quickly identify which keys go together to control a specific audio video device.



Issue date 2014-02-06

Version: 1.0.5

12 NC: 8670 000 41963
EAN: 87 12581 44081 7

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com