

Philips
CD Soundmachine with
Dynamic Bass Boost



AZ1021

Music on the move

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ1021 lets you indulge in the pleasures of enjoying your favourite music with the help of easy-to-use functions.

Enjoy your music from different sources

- CD player
- Compatible with CD-Recordable and CD-ReWritable
- FM/MW stereo tuner

Enriched bass sound

- Dynamic Bass Boost for deep and dramatic sound

Easy to use

- CD shuffle/program/repeat
- Multi-functional LCD display
- Stereo headphone socket

PHILIPS

Specifications

Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW
- Programmable Tracks: 20
- Disc Playback Modes: Fast Forward/Reverse, Next/Previous Track Search, Repeat Play, Shuffle Play

Tuner/reception/transmission

- Tuner Bands: FM, MW
- Antenna: FM Antenna

Sound

- Output power (RMS): 2 x 1 W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 3.5"
- Volume Control: rotary

Convenience

- Display Type: LCD
- Display Digits: 2



Connectivity

- Headphones: 3.5 mm

Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

Accessories

- Included Accessories: AC Power Lead, User manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D): 325 x 180 x 280 mm
- Product dimensions (W x H x D): 290 x 143 x 240 mm
- Weight: 1.76 kg
- Weight incl. Packaging: 2.32 kg

Highlights

CD player

CD player

CD-R/RW Compatible

CD-Rewritable Compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase-change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.

FM/MW stereo tuner

FM/MW stereo tuner

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

CD shuffle/program/repeat

CD shuffle/program/repeat

Multi-functional LCD display

Multi-functional LCD display

Stereo headphone socket

Stereo headphone socket



Issue date 2015-01-22

Version: 3.0.8

12 NC: 9073 101 02764
EAN: 87 10895 97811 8

© 2015 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com