

Philips  
Mini Hi-Fi System

MP3

FWM35



## MP3 playback with rich sound experience

Fulfill all your music needs with FWM35 MP3 Mini Hi-Fi System, which delivers superbly rich sound. Plus the freedom to savor 30 hours of your favorite MP3-CD music and intuitive ease-of-use make this set a joy to use!

### **Enrich your sound experience**

- 60W RMS total output power
- 2-Way Bass Reflex Speaker System for powerful sound

### **Longer listening, greater enjoyment**

- 30 hours of MP3-CD music playback
- 3-disc changer for convenient multi-disc playback
- Dual Logic Tape Deck with auto replay

### **Personalized sound settings**

- 3-step Dynamic Bass Boost for deep bass experience
- Digital Sound Control for optimized music style settings

# PHILIPS

# Highlights

## 60W RMS

This system has 60W RMS total output power. RMS refers to Root Mean Square which is a typical measurement of audio power, or rather, the electrical power transferred from an audio amplifier to a loudspeaker, which is measured in watts. The amount of electrical power delivered to the loudspeaker and its sensitivity determines the sound power that is generated. The higher the wattage, the better the sound power emitted by the speaker.

## 2-Way Bass Reflex System

2-Way Bass Reflex Speaker System for powerful sound

## 30 hours of MP3-CD music

MP3 stands for "MPEG 1 Audio layer-3".MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading

their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

## 3-disc changer

With a three-disc changer for music playback, you can choose between three different CDs inside the device at any one time. This convenient feature allows you to savor a variety of music while saving you precious time from changing CDs frequently.

## Dual Logic Tape Deck

Dual Logic Tape Deck with auto replay

## 3-step Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from level one to level three – at the

touch of a button! You can customize the bass level that fits your style. Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



# Specifications

## Sound

- Output Power: 2x30W RMS / 2x60W music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost 3 steps

## Loudspeakers

- Main Speaker: 2 way, 2" tweeter, 5.25" woofer, Bass Reflex Speaker System
- Number of Loudspeakers: 2

## Audio Playback

- Cassette Deck Technology: Full Logical
- Cassette Playback Modes: Fast Wind/Rewind
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: 99-Track Programmable, Repeat/one/disk/program, Shuffle Play
- Loader Type: 3 CD Carousel
- Number of decks: 2
- Number of Discs: 3

## Audio Recording

- Tape Recording Enhancement: Automatic Recording Level, CD Synchro Start Recording

## Tuner/Reception/Transmission

- Auto digital tuning
- RDS: News, Program Type, Radio Text, RDS Clock Set, Station Name
- Station presets: 40
- Tuner Bands: FM, MW
- Tuner Enhancements: Auto Store, Easy Set (Plug &

Play)

## Connectivity

- Aux in: Line-in
- Headphone: 3.5 mm
- Other connections: FM Antenna, MW Antenna

## Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: FTD
- Eco Power Standby: 1 watt
- Indications: DIM mode

## Accessories

- Included accessories: AC Power Cord, FM/MW Antenna
- Remote control: 21-key

## Dimensions

- Set dimensions (W x H x D): 265 x 310 x 367 mm
- Main speaker dimensions (W x H x D): 248 x 310 x 195 mm
- Packaging dimensions (W x H x D): 611 x 411 x 440 mm
- Weight incl. Packaging: 15.6 kg

## Power

- Power supply: 200-240 V, 50Hz
- Standby power consumption: <1W



Issue date 2014-02-05

Version: 5.0.6

12 NC: 9073 100 12445  
EAN: 87 10895 86624 8

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)